




Pilot's Operating Handbook

and Flight Training Supplement for

Alpha Electro

registered as LSA - 570 kg MTOM



Doc n. : POH-167-00-40-150

REV A00

(18th November, 2022)

SERIAL NUMBER _____

REGISTRATION NUMBER _____

For additional document applicability information, please refer to:
SB-160-00-80-999 Status of continuing airworthiness documentation

All rights reserved. Reproduction or disclosure to third parties of this document or any part thereof is not permitted, except with the prior and express written permission of Pipistrel Group's R&D division, Pipistrel Vertical Solutions d.o.o., which is authorized to publish technical documentation for Pipistrel Group's subsidiaries.



This page is intentionally left blank.

Performance - Specifications

ALPHA Electro	60 kW Electric
Stall speed (flaps extended +25°)	39 KIAS (72 km/h)
Stall speed (flaps retracted 0°)	44 KIAS (82 km/h)
Best endurance speed	85 KIAS (157 km/h)
VNE	135 KIAS (250 km/h)
Best endurance - not considering reserves *	60 min
Standard range at cruise	75 NM (139 km)
Takeoff - ground roll - at MTOM	595 ft (181 m)
Takeoff total distance over 50 ft obst. at MTOM	930 ft (285 m)
Landing distance over 50 ft obst.	1615 ft (492 m)
Absolute ceiling at MTOM	12,800 ft (3900 m)

* **NOTE** Legal flight time must be applied according to applicable local regulations!

NOTE The above performance figures are based on an airplane weight of 1256 lbs (570 kg), standard atmospheric conditions, level hard-surfaced dry runways and no wind. They are calculated values derived from flight tests conducted by Pipistrel, under the supervision of the Slovenian CAA and under carefully documented conditions. Figures may vary based on numerous factors (surface condition, temperature, water on wing, etc).

ALPHA Electro	60 kW Electric
Maximum weight takeoff	1256 lbs (570 kg)
Maximum weight landing	1256 lbs (570 kg)
Empty weight (incl. BPRS, no batteries, typical)	553 lbs (251 kg)
Battery capacity, total	21.0 kWh
Battery capacity, useful	20.0 kWh
Motor	60 kW E-Motor
Propeller	three blade, fixed pitch composite propeller, diameter 64 9/16" (1640 mm)

This aircraft is compliant with ASTM F2245 (design and construction) and ASTM F3198 for continued airworthiness. For a detailed compliance declaration please refer to the applicable LSA Compliance Statement as issued by the manufacturer for this aircraft's serial number."

Coverage

The Pilot's Operating Handbook (POH), found in the airplane at the time of delivery from Pipistrel, contains information applicable to the ALPHA Electro airplane and to the airframe designated by the serial number and registration number shown on the title page. All information is based on data available at the time of publication.

This POH consists of nine sections that cover all operational aspects of a standard equipped airplane. Section 9 contains the supplements which provide amended operating procedures, performance data and other necessary information for those airplanes that conduct special operations and/or are equipped with both standard and optional equipment. Additional supplements are individual documents which are issued/revised separately. The log of effective pages should be used to determine the status of each supplement.

Revision tracking, filing and identifying

Pages to be removed or replaced in the Pilot's Operating Handbook are determined by the log of effective pages located in this section. This log contains the page number and revision number for each page within the POH. As revisions to the POH occur, the revision number on the effected pages is updated. When two pages display the same page number, the page with the latest revision shall be used in the POH. The revision number on the log of effective pages shall also coincide with the revision number of the page in question. As an alternative to removing and/or replacing individual pages, the owner can also print out a whole new manual in its current form, which is always available from www.pipistrel-aircraft.com.

Revised material is marked with a vertical bar that will extend the full length of deleted, new, or revised text added to new or previously existing pages. This marker will be located adjacent to the applicable text in the margin on the outer side of the page. The same system applies when the header, figure, or any other element inside this POH is revised. A list of revisions is located at the beginning of the log of effective pages. Pipistrel is not responsible for technical changes/updates to OEM manuals supplied with the aircraft (eg. radio, transponder, GPS, etc.).

Warnings, cautions and notes

Safety definitions used in the manual:

WARNING! Disregarding the following instructions leads to severe deterioration of flight safety and hazardous situations, including such resulting in injury and loss of life.

CAUTION! Disregarding the following instructions leads to serious deterioration of flight safety.

NOTE An operating procedure, technique, etc., which is considered essential to emphasize.

Online updates, service notice tracking

For updates and information related to service/airworthiness, please go to www.pipistrel-aircraft.com and log in with:

Username: aetechpub
Password: AE2020!

Abbreviations legend

AC	- Anti-collision
EA	- Electric Aircraft
EAW	- Empty Aircraft Weight
BMS	- Battery management system
BPRS	- Ballistic parachute rescue system
CAS	- Calibrated Air Speed
COM	- Communication
ELT	- Emergency locator transmitter
ft	- Feet
IAS	- Indicated airspeed
IFR	- Instrument flight rules
IMC	- Instrument meteorological conditions
KCAS	- Calibrated Air Speed - Knots
kg	- Kilogram
KIAS	- Indicated airspeed - Knots
km/h	- Kilometers per hour
kts	- Knots
kW	- Kilowatt
kWh	- Kilowatt hour
LDG	- Landing gear
m	- Meters
MAC	- Mean aerodynamic chord
MCP	- Maximum continuous power
MTOW/MTOM	- Maximum takeoff weight/Maximum takeoff mass
NAV	- Navigation
POH	- Pilot's operating handbook
PWR	- Power
RPM	- Revolutions per minute
SOC	- State of charge
SOH	- State of health
sqft	- Square feet
TC	- Power module of the charger
V	- Volt
VAC	- Volts alternating current
VFR	- Visual flight rules

Index of revisions

The table below shows the revision history of this POH. Check your registration authority's or the manufacturer's website occasionally for the most up-to-date releases of operation-relevant documentation, which includes this POH.

Designation	Reason for Revision	Release date	Affected pages	Issuer
REV A00	Initial issue	18 th November, 2022	All	SLO.DOA.002

Log of Effective Pages

Use the table below to determine the currency and applicability of your POH. Pages affected by the current revision are marked in bold text in the page number column.

Page number	Page status	Rev. number	Page number	Page status	Rev. number
Cover	Original	-	3-7	Original	0
i-1	Blank Page	-	3-8	Original	0
i-2	Original	0	4-1	Original	0
i-3	Original	0	4-2	Original	0
i-4	Original	0	4-3	Original	0
i-5	Original	0	4-4	Original	0
i-6	Original	0	4-5	Original	0
i-7	Original	0	4-6	Original	0
0-1	Original	0	4-7	Original	0
0-2	Blank Page	-	4-8	Original	0
1-1	Original	0	4-9	Original	0
1-2	Original	0	4-10	Original	0
1-3	Original	0	5-1	Original	0
1-4	Original	0	5-2	Original	0
1-5	Original	0	5-3	Original	0
1-6	Original	0	5-4	Original	0
2-1	Original	0	5-5	Original	0
2-2	Original	0	5-6	Original	0
2-3	Original	0	5-7	Original	0
2-4	Original	0	5-8	Blank Page	0
2-5	Original	0	6-1	Original	0
2-6	Original	0	6-2	Original	0
2-7	Original	0	6-3	Original	0
2-8	Original	0	6-4	Original	0
2-9	Original	0	7-1	Original	0
2-10	Original	0	7-2	Original	0
2-11	Original	0	7-3	Original	0
2-12	Blank Page	-	7-4	Original	0
3-1	Original	0	7-5	Original	0
3-2	Original	0	7-6	Original	0
3-3	Original	0	7-7	Original	0
3-4	Original	0	7-8	Original	0
3-5	Original	0	7-9	Original	0
3-6	Original	0	7-10	Original	0

CAUTION!

This manual is valid only if it contains all of the original and revised pages listed above. Each page to be revised must be removed, shredded and later replaced with the new, revised page in the exact same place in the manual.

Log of Effective Pages (continued)

Page number	Page Status	Rev. number
7-11	Original	0
7-12	Blank page	-
8-1	Original	0
8-2	Original	0
8-3	Original	0
8-4	Original	0
8-5	Original	0
8-6	Blank Page	-
9-1	Original	0
9-2	Original	0
9-3	Original	0
9-4	Original	0
9-5	Original	0
9-6	Original	0
9-7	Original	0
9-8	Original	0
9-9	Original	0
9-10	Original	0
9-11	Original	0
9-12	Original	0
9-13	Original	0
9-14	Original	0
9-15	Blank Page	-
Back-cover	Original	-

Table of contents

1 General

2 Limitations

3 Emergency Procedures

4 Normal Procedures

5 Performance

6 Weight and Balance

7 Airplane & Systems

8 Handling and Servicing

9 Appendix



This page is intentionally left blank.

1 General



Introduction (1-2)

Technical brief (1-2)

3-view drawing (1-3)

Propulsion system (1-4)

Weights (1-5)

Center of gravity range (1-6)

G-load factors (1-6)

Introduction

This manual contains all the information needed for appropriate and safe use of ALPHA Electro .

IT IS MANDATORY TO CAREFULLY STUDY THIS MANUAL BEFORE USING THE AIRCRAFT.

Pipistrel is not responsible for any damage or injury resulting from not following the instructions contained in this manual.


All text, design, layout and graphics are owned by Pipistrel. All rights reserved. Reproduction or disclosure to third parties of this document or any part thereof is not permitted, except with the prior and express written permission of Pipistrel Group's R&D division, Pipistrel Vertical Solutions d.o.o., which is authorized to publish technical documentation for Pipistrel Group's subsidiaries.

This document **MUST** be present inside the cockpit at all times.
 Should you sell this aircraft make sure this document is given to the new owner.

Technical brief

DIMENSIONS	ALPHA Electro
Wing span	10.50 m (34' 5 3/8")
Length	6.47 m (21' 2 3/4")
Height	2.05 m (6' 8 11/16")
Wing surface	9.29 m ² (100 sqft)
Vertical fin surface	1.1 m ² (11.84 sqft)
Horizontal stabilizer and elevator surface	1.08 m ² (11.62 sqft)
Wing aspect ratio	11.8
Positive flap settings	0°, 15°, 25°
Center of gravity (% MAC) - Range limits	20% - 35%

3-view drawing



Propulsion system

WARNING! The motor is not certified for aviation use, therefore, there is no assurance it won't fail during operation at any given moment, without prior notice.

Motor

TEMPERATURE °C	PEM 60MVLC
Maximum takeoff power (1 min)	56 kW
Maximum continuous power	50 kW
Maximum operating temperature	90° C
Maximum ambient temperature	40° C
RPM	PEM 60MVLC
Maximum allowable rpm	2500
Takeoff RPM (typical)	2400
Climb RPM (typical)	2250

Power controller

POWER CONTROLLER	H300A
Nominal power	60 kW
Maximum operating temperature	65° C
Maximum ambient temperature	40° C

WARNING! Do not, under any circumstances, attempt to use any other batteries other than Pipistrel factory-supplied batteries. Only use them with the motor and power controller mentioned in this POH.

Battery system

Battery system	PB345V105E-A
Maximum voltage	398 V
Minimum voltage	288 V
Recommended voltage range for storage	355 V - 365 V
Maximum operating temperature	55° C
Minimum operating temperature	5° C
Allowable temperature range for storage	10° C - 40° C
Minimum charging temperature	0° C
Maximum battery temperature before takeoff	40° C

CAUTION! Temperatures below 10°c will cause a decrease in battery capacity. Plan your flight accordingly.

WARNING! Do not, under any circumstances, attempt to charge the batteries with any third party chargers. Only Pipistrel original equipment must be used.

WARNING! Respect operating and storage temperature limits at all times. Failure to do so may result in battery damage.

Propeller

ALPHA Electro	FP03-60E
three blade, fixed pitch composite propeller	64 1/16" (1640 mm)

Motor instrument markings

Instrument	Red (minimum)	Yellow (caution)	Green (normal)	Yellow (caution)	Red line (maximum)
Tachometer (RPM)	/	/	0 - 2399	2400 - 2499	2500
Motor temp. (°C)	/	/	(-20) - 89	90 - 94	95
Power controller temp. (°C)	/	/	(-20) - 59	60 - 64	65
Battery sys. temp. (°C)	5	6 - 10	11 - 44	45 - 49	50

Weights

Basic model weights

WEIGHT	ELECTRO
Empty aircraft weight (incl. BPRS and std. battery system - typical)	368 kg (811 lbs)
Maximum takeoff weight (MTOM)	570 kg (1256 lbs)
Minimum combined cockpit crew weight (depends on C.G. of empty aircraft)	55 kg (121 lbs)
Maximum combined cockpit crew weight (depends the weight and balance)	see Chapter 6

WARNING! Should one of the above-listed values be exceeded, others must be reduced in order to keep the MTOM below 570 kg (1256 lbs). Failing to comply with any of the weight limitations may cause uncontrolled ground handling and/or flight due to extreme center of gravity position.

Center of gravity range

- The aircraft's safe in-flight center of gravity position ranges between 20% and 35% of mean aerodynamic chord.
- The in-flight center of gravity point ranges between 8 1/16" (220 mm) and 14" (355 mm) aft of the datum. The datum is the wing's leading edge at the fuselage root.

G-load factors

Max. positive wing load: + 4 G

Max. negative wing load: - 2 G

2 Limitations



Introduction (2-2)

Airspeed limitations (2-2)

Powerplant limitations (2-3)

Weight limits (2-4)

Center of gravity range (2-4)

G-load factors (2-5)

Service ceiling, crosswind (2-5)

Maneuver limits (2-5)

Kinds of operations (2-6)

Minimum equipment list (2-6)

Energy limitations (2-6)

Other restrictions (2-7)

Placards (2-8)

Introduction

This section includes operating limitations, instrument markings and basic placards necessary for the safe operation of the airplane, it's motor, standard system and standard equipment.
Adhering to the limitations outlined in this section is required by law.

Airspeed limitations

NOTE: airspeeds in the table are IAS

	Velocity	IAS [kts (km/h)]	Remarks
V_{S0}	Stall speed landing configuration	39 (72)	Stall speed flaps extended +25°
V_S	Stall speed clean	44 (82)	Stall speed flaps retracted 0°
V_{FE}	Max. velocity flaps extended	70 (130)	Do not exceed this speed with flaps extended +15°.
		60 (111)	Do not exceed this speed with flaps extended +25°.
V_A	Design maneuvering speed	93 (172)	Do not make full or abrupt control movements above this speed.
V_{NE}	Velocity never to be exceeded	135 (250)	Never exceed this speed in any operation.
V_{NO}	Velocity normal operating	108 (200)	Maximum structural cruising speed in turbulent air (V _C).

Airspeed indicator markings

MARKING	IAS [kts (km/h)]	Definition
White band	39 - 70 (72 - 130)	Full Flap Operating Range. Lower limit is the maximum weight V _{S0} in landing configuration. Upper limit is maximum speed permissible with flaps extended.
Green band	44 - 108 (82 - 200)	Normal Operating Range Lower end is maximum weight V _S at most forward C.G. with flaps retracted. Upper limit is maximum structural cruising speed.
Yellow band	108 - 135 (200 - 250)	Maneuver the aircraft with caution in calm air only.
Red line	135 (250)	Maximum speed for all operations. V _{NE}
/	70 (130)	Best climb rate speed (V _Y)
/	55 (102)	Best angle of climb speed (V _X)

Powerplant limitations

WARNING! The motor is not certified for aviation use, therefore, there is no assurance it cannot fail in its operation at any given moment, without prior notice.

Motor

TEMPERATURE °C	PEM 60MVLC
Maximum takeoff power (1 min)	56 kW
Maximum continuous power	50 kW
Maximum operating temperature	95 °C
Maximum ambient temperature	40 °C
RPM	PEM 60MVLC
Maximum allowable	2500
Takeoff RPM (typical)	2400
Climb RPM (typical)	2250

Power controller

POWER CONTROLLER	H300A
Nominal power	60 kW
Maximum operating temperature	65 °C
Maximum ambient temperature	40 °C

WARNING! Do not, under any circumstances, attempt to use any other batteries other than Pipistrel factory-supplied batteries. Only use them with the motor and power controller mentioned in this POH.

Battery system

Battery system	PB345V105E-A
Maximum voltage	398 V
Minimum voltage	288 V
Recommended voltage range for storage	355 V - 365 V
Maximum operating temperature	55° C
Minimum operating temperature	5° C
Allowable temperature range for storage	10 °C - 40 °C
Minimum charging temperature	0 °C
Maximum battery temperature before takeoff	40 °C

CAUTION! Temperatures below 10°c will cause a decrease in battery capacity. Plan your flight accordingly.

WARNING! Do not, under any circumstances, attempt to charge the batteries with any third party chargers. Only Pipistrel original equipment must be used.

WARNING! Respect operating and storage temperature limits at all times. Failure to do so may result in battery damage.

Propeller

ALPHA Electro	Propeller
with 60 kW electric motor	three blade, fixed pitch composite propeller, diameter 64 9/16" (1640 mm)

Motor instrument markings

Instrument	Red (minimum)	Yellow (caution)	Green (normal)	Yellow (caution)	Red line (maximum)
Tachometer (RPM)	/	/	0 - 2399	2400 - 2499	2500
Motor temp. (°C)	/	/	(-20) - 89	90 - 94	95
Power controller temp. (°C)	/	/	(-20) - 59	60 - 64	65
Battery sys. temp. (°C)	5	6 - 10	11 - 44	45 - 49	50

Weight limits

Basic model weights

WEIGHT	ELECTRO
Empty aircraft weight (incl. BPRS and std. battery system)	368 kg (811 lbs)
Maximum takeoff weight (MTOM)	570 kg (1256 lbs)
Minimum combined cockpit crew weight (depends on C.G. of empty aircraft)	55 kg (121 lbs)
Maximum combined cockpit crew weight (depends the weight and balance)	see Chapter 6

WARNING! Should one of the above-listed values be exceeded, others **MUST** be reduced in order to keep MTOM below 570 kg. failing to comply with any of the weight limitations may cause uncontrolled ground handling and/or flight due to extreme center of gravity position.

Center of gravity range

- The aircraft's in-flight safe center of gravity position ranges between 20% and 35% of MAC (mean aerodynamic chord).
- The in-flight center of gravity point ranges between 8 1/16" (220 mm) and 14" (355 mm) aft of the datum. The datum is the wing's leading edge at the fuselage root.

G-load factors

Max. positive wing load: + 4 G

Max. negative wing load: - 2 G

Service ceiling, crosswind

Service ceiling is 12,800 ft (3900 m). Maximum crosswind component is 18 kts.

Maneuver limits

The following NON-aerobatic maneuvers are permitted as defined:

Power-on and -off stalls not below 1500 feet (450 meters) above ground level.

Power on and off lazy eights not below 1500 feet (450 meters) above ground level, entry speed 90 kts.

Steep turns with initial speed of 80 kts.

Chandelle maneuvers not below 500 ft (150 m) above ground level, entry speed 105 kts.

WARNING! Aerobatic maneuvers, including intentional spins, are prohibited.

Kinds of operations

**ALPHA Electro can be used for DAY - VFR operations only.
Flight into known icing conditions is prohibited.**

WARNING! Should you find water drops on the airframe during pre-flight check-up at temperatures close to freezing, you may expect icing to appear in flight.

Minimum equipment list (DAY - VFR)

- Placards, checklist, this POH
- Airspeed indicator (functional), Altimeter (functional), Compass (functional)
- EPSI570
- Both battery packs (functional), Safety belts (2x)

Energy limitations

Description:	2 metal boxes(packs) which include battery cells, BMS and communication modules, power and signal connectors
Total battery capacity:	21.0 kWh
Useful bat. capacity:	20.0 kWh
Maximum allowed output power with one battery pack connected	35 kW

NOTE The system will function with only one of the battery packs connected, however, the power output must be kept below 35 kW.

WARNING! Takeoff is prohibited with a SOC (state of charge) below 40%.

Other restrictions

Due to flight safety reasons it is forbidden to:

- fly in heavy rainfall
- fly during thunderstorm activity;
- fly in a blizzard
- fly according to Instrument Flight Rules (IFR) or attempt to fly in instrument meteorological conditions (IMC)
- fly when the temperature of the aircraft's surface is at risk of exceeding 55 °C (130 °F)
- perform aerobatic flying
- take off with flaps retracted (0°)
- land with flaps retracted (0°), other than in cases of very strong winds (not to be performed as a normal procedure)
- the 12 Volt power outlet is not approved to supply power to flight-critical communication or navigation devices
- take off when state of charge is below 40%
- fly with either of the battery packs removed

Placards

Placards (external):

Next to door opening latches:



Next to wheels:




or



Next to FCP:



or



Next to battery bay
door lock:



Next to battery bay
cooling outlets:





Placards (motor compartment):




On overflow bottle :



On junction box and battery packs:



Placards (center console and instrument panel):



Next to microphone jacks:





Next to headphone jacks:




In front of control sticks
(rudder pedal adjustment):



Right side of the instrument panel :




Next to power lever:



Next to wheel brake lever:



On flap lever:



Below each door to depict door handle operation:




On upper tube in front of pilot:



Placards (Ballistic BPRS):


On BPRS hatch:



Next to activation
handle (cockpit):



Next to rocket exhaust
(bottom of fuselage):



Next to each door, top aft corner:





This page is intentionally left blank.

3 Emergency procedures



Introduction (3-2)

Stall recovery (3-2)

Spin recovery (3-2)

Motor failure (3-2)

Emergency landing (3-3)

Fire (3-3)

Smoke in cockpit (3-3)

EPSI570 failure (3-4)

Flutter (3-4)

Battery failure (3-4)

Exceeding VNE (3-4)

BPRS (3-4)

Ditching (3-5)

**Powerplant components
overtemperature (3-5)**

EPSI570 user action guide (3-7)

Introduction

This chapter provides information on how to react when confronted with typical flight hazards.

NOTE See EPSI570 user action guide at the end of this chapter for a complete list of system warnings and cautions that can appear on the EPSI570 during operation.

Stall recovery

1. Reduce the angle of attack by easing-off on the control stick.
2. If the motor is running, add full power.
3. Resume horizontal flight.

Spin recovery

The ALPHA Electro is constructed in such a manner that it is difficult to fly it into an inadvertent spin. However, once spinning, react as follows:

1. If the motor is running, set power to “cut off”(lever in full back position).
2. Apply full rudder deflection in the direction opposite to spin direction.
3. Lower the nose towards the ground to build up speed (release stick force to neutral).
4. As the aircraft stops spinning neutralise rudder deflection.
5. Slowly pull up and regain horizontal flight (do not exceed airspeed and g-load limits).

ALPHA Electro tends to recover from spin by itself after spinning about 90°.

WARNING! Keep the control stick centered along its lateral axis (no aileron deflections throughout the recovery phase!).

WARNING! After the aircraft stops spinning, recovering from the dive must be performed using gentle stick movements (pull), rather than over-stressing the aircraft. However, VNE must not be exceeded during this maneuver.

Resume normal flight when the aircraft is straight and level.

Motor failure

Motor failure during takeoff or initial climb

Ensure proper airspeed by lowering the nose and land the aircraft in runway heading, avoiding eventual obstacles in your way. Set master switch to the OFF position. Land straight ahead.

WARNING! Do not change course or make turns if this is not of vital necessity! After having landed safely, ensure protection of the aircraft and vacate the runway to keep the runway clear for arriving and departing traffic.

Do this calmly and carefully not to cause damage to yourself and any equipment.

Motor failure in climb

First ensure proper airspeed by lowering the nose, then start scanning the terrain underneath and choose the most appropriate site for landing out.

WARNING! The decision where to land when landing out is final! Changing your mind, even if you happen to come across a different, perhaps more appropriate landing site, should be your last resort.

Motor restart in flight

NOTE: The minimum height, at which a motor restart attempt can be made safely, is 1000 ft AAL.

1. Set the **POWER LEVER** to **CUT OFF**
2. Set **PWR EN SWITCH** to **OFF**
3. Set **MASTER SWITCH** to **OFF**
4. **DISENGAGE** the **PWR CTRL Circuit breaker**

After 3 seconds:

5. **ENGAGE** the **PWR CTRL Circuit breaker**
6. Set **MASTER SWITCH** to **ON**
7. Set **PWR EN SWITCH** to **ON**
8. **SLOWLY INCREASE** the **POWER LEVER**

If restart is not successful, perform an emergency landing.

Emergency landing

1. Master switch **OFF**.
2. Fasten your seat harness tightly.
3. Approach and land with extreme caution with +10 km/h (+5 kts) airspeed reserve if the chosen landing terrain length permits.
4. Leave the aircraft immediately after landing.

Fire

Powertrain fire on ground

Should you encounter motor fire on the ground, react as follows:

1. Come to a complete standstill, master switch **OFF** and disengage **PWR CTRL circuit breaker**.
2. Abandon the aircraft and start extinguishing the fire with a waterless agent.

WARNING! After the fire has been extinguished **DO NOT** attempt to restart the motor.

Powertrain fire in flight

Should you encounter motor fire in flight, react as follows:

1. Set master switch to **OFF** and disengage **PWR CTRL circuit breaker**.
2. Open all cabin vents.
3. Perform side-slip (crab) maneuver in direction opposite the fire.
4. Perform emergency landing procedure and leave the aircraft immediately.

Battery system fire

Indication of battery fire is dense smoke and a distinctive chemical smell. Disengage both battery circuit breakers, land immediately and leave the aircraft as soon as possible.

WARNING! Be aware that lithium battery fires are extremely dangerous because they are self-sustaining! They are a result of chemical reactions and are impossible to extinguish. You can only prevent or delay fire propagation by continually cooling down the batteries and surrounding items with a copious amount of water.

Smoke in cockpit

1. Set master switch to OFF.
2. Open all cabin vents for adequate breathing.
3. Land as soon as possible.

EPSI570 failure

While on the ground:

During taxi: Do not takeoff!

During takeoff run: If possible and safe, abort the takeoff procedure!

While in flight:

Without power to the motor: Look for a spot to carry out a safe outlanding. If practical check the circuit breakers, disengage the system's four main switches, power lever to cut-off, and attempt a re-start.

With power to the motor: Do not switch the motor off. Attempt to fly to the next airfield and land as practical.

Flutter

Flutter is described as the oscillation of control surfaces. In most cases it is caused by abrupt control deflections at speeds close to or in excess of VNE. As it occurs, the ailerons, elevator or even the whole aircraft start to vibrate violently.

Should flutter occur, pull on the stick and reduce power immediately!

WARNING! Fluttering of ailerons or tail surfaces may cause permanent structural damage and/or inability to control the aircraft.

After a safe landing, the aircraft **MUST** undergo a series of check-ups performed by authorised service personnel to verify airworthiness.

Exceeding VNE

Should the VNE be exceeded, reduce airspeed slowly and continue flying using gentle control deflections. Land safely as soon as possible and have the aircraft verified for airworthiness by authorised service personnel.

BPRS

Please refer to Appendix (9-2) for information about the use of Ballistic Parachute Rescue System during emergency.

Battery failure

With two battery packs on board the battery system is automatically redundant. A failure of one battery pack will be displayed on EPSI570 as a warning and the system will automatically switch to a single-battery mode, enabling continuation of flight. Land as soon as practical and have the battery system verified by authorised personnel.

WARNING! Single battery operation is considered an emergency situation in which the maximum power output must be kept below 35 kW! Plan actions and maneuvers accordingly.

Ditching

1. **Airspeed - Set airspeed for best glide**
2. **Flaps - set position 0**
3. **Throttle - cut off**
4. **Disengage both battery circuit breakers (HV BAT.1/.2)**
5. **Life vests - check**
6. **Items in cabin - secure**
7. **Seat belts - check fastened and tighten**
8. **Radio - set 121.5 MHz and transmit "MAYDAY, MAYDAY, MAYDAY, ..."**
9. **Transponder - Set to 7700**
10. **Approach - high seas and high wind into the wind, light wind heavy swells parallel to the coastline**
11. **Doors - unlatch/ unlock**
12. **Master - OFF**
13. **Disengage PWR CTRL circuit breaker**
14. **Flaps - set to max extension before making contact with the surface**
15. **Landing - make contact with water surface at the lowest possible speed**
16. **Seat belts - release immediately**
17. **Aircraft - exit as soon as possible**
18. **Life vest and raft - inflate when outside the cabin**

Powertrain components overtemperature

Continuous monitoring and a careful management (power setting) of powertrain components temperature is essential for flight safety. Motor, power controller and battery temperatures are displayed on the EPSI570 screen in the form of vertical bar-type indicators. Temperature ranges (normal, caution, warning) are indicated beside each vertical bar. Please see Section 2 - Limitations - Motor instrument markings - for applicable temperature range values.

Motor, power controller and battery temperatures are influenced mostly by two factors: ambient temperature and power setting. The pilot has direct control of the power setting and thus affects the powertrain component temperatures. Avoid high power setting for long periods, especially in a hot environments (80-85 °F/26-30 °C and higher). Flight speed also has influence on cooling, as it increases airflow through the cooler.

Automatic power reduction

Exceeding normal operating temperatures must be avoided as it may lead to automatic power reduction and eventual power cut off.

POWER CONTROLLER

Linear power reduction is applied above 65 °C, up to 68 °C, reduced by 30 kW every °C of temperature increase. Power is cut off when the temperature exceeds 68 °C. Overtemperature of the power controller is critical, as the power cut off temperature is reached very quickly. Power controller overtemperature is indicated by "DRIVE OVERTEMPERATURE" warning message. The actual temperature value is visible on the bar-type indicator.

Special care shall be taken not to allow the temperature of the power controller to exceed 60°C (caution range).

Should the temperature of the power controller reach 60 °C during cruise flight operations or maneuvering, reduce power immediately to a cruise power setting of maximum 25 kW and place the aircraft in level flight until the power controller cools below 55 °C. The aircraft can climb at 25 kW at maximum MTOM, but rate of climb is very low.

No take-off shall be initiated if the power controller temperature is 55 °C or higher. However, if the power controller reaches 60 °C during take-off, power should be immediately reduced to 40 kW and climb angle reduced to increase forward speed to 70 kts to increase cooling. The flight shall be terminated as soon as practical and measures taken to ensure the power controller temperature stays below 60 °C.

MOTOR

Linear power reduction is applied above 90 °C of motor temperature, up to 110 °C, where power is reduced to zero. Motor overtemperature is indicated by "DRIVE OVERTEMPERATURE" warning message. The actual temperature value is visible on the bar-type indicator.

BATTERY

Battery overtemperature is indicated by "BATTERY 1/2 OVERTEMPERATURE" caution message on the EPSI570 display and power is cut when batteries reach 60 °C.

Reduce power to 35 kW or less if one battery is disconnected, monitor temperatures and SOC of the functional battery and land as soon as practical.

EPSI570 user action guide

Warning and Caution messages	
CAUTION (orange)	User action
BATTERY 1/2 OVERTEMPERATURE (at battery temp. 45°C)	<ul style="list-style-type: none"> - Reduce power - Monitor battery temperature - Land as soon as practical if the problem persists
SOC < 10%	<ul style="list-style-type: none"> - Power lever cut off - Land as soon as practical - monitor the residual %SOC (battery will disconnect by itself, depends on the cell voltage)
BATTERY 1/2 SOC ADJUSTED	<p>This message indicates that a SOC estimation failure has occurred. The SOC will be updated to a more conservative and safe value. Reset the message by pressing the knob.</p> <ul style="list-style-type: none"> - Change the flight plan according to the updated SOC value.
WARNING (red)	User action
ONLY ONE BATTERY PACK IS ACTIVE	<p>This warning appears when power controller is ON and when motor RPM exceeds 300. This message is meant to avoid the possibility of taking off with only one pack active.</p> <ul style="list-style-type: none"> - if appears while on the ground: do not takeoff - if appears during flight: reduce power to 35 kW or less. Land as soon as practical
BATTERY 1/2 NOT PRESENT	<p>This warning means that the battery is not detected by the system.</p> <ul style="list-style-type: none"> - If this occurs on the ground do not take-off and check battery installation - If this occurs in flight reduce power to 35 kW or less, land as soon as practical
BATTERY 1/2 DISCONNECTED DUE TO [DISC CURRENT, CHG CURRENT, OVERTEMP, INTERLOCK, UNDERVOLTAGE, OVERVOLTAGE]	<p>OVERTEMPerature (at 55°C), DISCharge CURRENT and cell UNDERVOLTAGE warnings only appear while flying. The message indicates that the system has automatically disconnected a battery pack due to the reason described.</p> <ul style="list-style-type: none"> - Reduce power immediately to 35 kW or less (battery will disconnect by itself) and land as soon as practical
BATTERY 1/2 DISBALANCED REDUCE POWER	<ul style="list-style-type: none"> - Reduce power - Reset message and monitor system status
BATTERY 1/2 STARTUP FAILED EC: [X]	<p>This warning appears after turning the power enable switch on during ground operation. »X« represents the error number.</p> <ul style="list-style-type: none"> - Do not take-off - NOTE the number - Report error number to technical support at maintenance@pipistrel.si
DRIVE OVERTEMPERATURE	<p>This warning appears when maximum power controller or motor temperature is exceeded.</p> <ul style="list-style-type: none"> - Reduce power immediately (to minimum possible) - Monitor motor/power controller temperature - Land as soon as practical if the problem persists but power is still available (possible power reduction) - Land as soon as possible (emergency) if power is cut off by the system
DRIVE TEMPERATURE SENSOR FAILURE	<p>WARNING! The power controller may reduce power to 0 if and when sensor failure happens.</p> <ul style="list-style-type: none"> - Land as soon as possible

DRIVE COMMUNICATION FAILURE	<p>The warning only appears during ground operation.</p> <ul style="list-style-type: none"> - in this case the start-up is not possible
COOLANT SENSOR FAILURE	<ul style="list-style-type: none"> - Reduce power - Monitor temperatures - Land as soon as practical
COOLANT PUMP FAILURE	<ul style="list-style-type: none"> - If appears while on the ground: do not take-off - If appears during flight: power controller temperature will rise very fast and motor power will be eventually cut. Reduce power, check temperatures. Land as soon as possible
DC/DC COMMUNICATION FAILURE	<ul style="list-style-type: none"> - If this occurs on the ground do not take-off - If this occurs in flight land as soon as practical
DC/DC MALFUNCTION	<ul style="list-style-type: none"> - If this occurs on the ground do not take-off - If this occurs in flight land as soon as practical
DC/DC NOT WORKING	<p>This warning appears when motor RPM exceeds 300.</p> <ul style="list-style-type: none"> - If this occurs on the ground do not take-off - If this occurs in flight land as soon as practical
POWER LEVER COMMUNICATION FAILURE	<p>When this warning appears the power setting will stay on the last value.</p> <p>If the available power is enough to maintain level flight:</p> <ul style="list-style-type: none"> - Land at the nearest airfield - When the touch-down point is within the gliding cone, disengage the PWR CTRL circuit breaker and perform an emergency engine-out landing <p>If the available power is NOT enough to maintain level flight or is higher than MCP:</p> <ul style="list-style-type: none"> - Locate a suitable landing spot - When the available power is not needed anymore, disengage the PWR CTRL circuit breaker and perform an emergency outlanding
DRIVE AUX POWER FAILURE	<p>When this error appears, the motor and power controller don't have power. This error only appears during ground operation.</p>
PUMP AUX POWER FAILURE	<p>This warning indicates water pump failure and only appears during ground operation.</p>

4 Normal procedures



Daily inspection (4-2)

Pre-flight inspection (4-2)

**Cockpit pre-flight
inspection (4-5)**

**Minimum conditions for
active motor (4-5)**

**Normal procedures and
recommended speeds (4-6)**

Daily inspection

The daily inspection is the same as the pre-flight inspection.


Pre-flight inspection

WARNING! Every single inspection mentioned in this chapter must be performed prior to every flight regardless of when the previous flight took place!

The person responsible for the pre-flight inspection is the pilot, who is required to perform the check-up in the utmost thorough and precise manner.

If the status of any of the parts and/or operations does not comply with conditions stated in this chapter, the damage MUST be repaired prior to motor start-up. Disobeying these instructions may result in serious additional damage to the plane and crew, including injury and loss of life!

Schematic of pre-flight inspection



- | | | |
|------------------------------|--------------------------------|------------------------------|
| 1 Motor, motor cover | 9 Right wing - continued | 17 Batteries back |
| 2 Propeller | 10 Fuselage (RH side) | 18 Left wing - continued |
| 3 Spinner, nose wheel | 11 Fuselage, continued (right) | 19 Left wing - trailing edge |
| 4 Batteries front | 12 Hor. tail surfaces (right) | 20 Left wing tip, lights |
| 5 Undercarriage, RH wheel | 13 Vert. tail surfaces (right) | 21 Left wing - leading edge |
| 6 Right wing - leading edge | 14 Vert. tail surfaces (left) | 22 Undercarriage, LH wheel |
| 7 Right wing tip, lights | 15 Hor. tail surfaces (left) | |
| 8 Right wing - trailing edge | 16 Fuselage, continued (left) | |

Motor, motor cover ①

Cooling fluid level: expansion tank full, overflow bottle between min and max *

Radiators and hoses: no mechanical damage and/or leakage

Fasteners and motor cover screws: tightened, motor cover undamaged, charge port door secured

*Do the cooling fluid level check only before every first flight of the day.

Batteries front ④

Battery packs: inserted and 4 pins secured, door closed and latched.

Battery bay cooling inlet: free of all/any obstructions.

Battery pack COM and PWR cables: connected.

Spinner ③

Spinner: no mechanical damage (e.g. cracks, impact spots), screws tight

Bolts and nuts: secured

Nose wheel: grab aircraft's propeller and push it towards the ground to verify proper nose wheel suspension operation. Then lift the nose wheel off the ground and check for nose leg strut free play.

Bolts: fastened

Tire: no cracks, adequate pressure

Wheel fairing: undamaged, firmly attached, clean (e.g. no mud or grass on the inside)

Propeller ②

Hub and blades: no mechanical damage (e.g. cracks), surface immaculately clean

Bolts and nuts: secured

Undercarriage, wheels ⑤ ②②

Bolts: fastened

Landing gear strut: no mechanical damage (e.g. cracks), clean

Wheel: no mechanical damage (e.g. cracks), clean

Wheel axle and nut: fastened

Fluid line (hydraulic brakes): no mechanical damage and/or leakage

Tire: no cracks, adequate pressure

Batteries back ①⑦

Battery packs: inserted and secured, door closed and latched.

Battery bay cooling inlet: free of all/any obstructions.

Battery pack COM and PWR cables: connected.

Wing leading edge ⑥ ②①

Surface condition: pristine, no cracks, impact spots, no paint and/or edge separations

Pitot tube: firmly attached, no mechanical damage or bends. Remove protection cover and make sure it is not blocked or full of water.

Wing drain holes: make sure they are not blocked and clean accordingly.

Wing tip, lights ⑦ ⑳

Surface condition: pristine, no cracks, impact spots or bumps, no paint separations

Wings' trailing edge ⑧ ⑲

Surface condition: pristine, no cracks, impact spots, no paint and/or edge separations

Aileron: pristine surface, no cracks and/or impact spots, no paint abnormalities and edge separations, no vertical or horizontal free play, smooth and unobstructed deflections

Charger door ⑨ ⑱

Charger door: secured.

Fuselage, antenna, rescue parachute cover ⑩ ⑰

Kevlar belt covers: firmly attached, not damaged

Flaperon control system cover, antenna: firmly attached

Fuselage, continued ⑪ ⑯

Surface condition: pristine, no cracks, impact spots or bumps, no paint separations

Horizontal tail surfaces ⑫ ⑮

Surface condition: pristine, no cracks, impact spots or bumps, no paint and/or edge separations

Hinges: no free play in any direction

Horizontal stabilizer attachment mechanism: fastened and secured

Mylar seals covering the gap between horizontal tail surfaces: in position

Elevator: smooth and unobstructed up-down movement, no side-to-side free play

Vertical tail surfaces ⑬ ⑭

Vertical fin bottom part: no cracks, impact spots or paint separations along main chord

Surface condition: pristine, no cracks, impact spots or bumps, no paint separations

Hinges: no free play in any direction

Rudder cable endings: intact, bolts in position

Mylar seals covering the gap between vertical tail surfaces: in position

Cockpit pre-flight inspection

BPRS activation handle safety pin:	- IN POSITION AND SECURED
Main wing spars and connectors:	- NO VISIBLE ABNORMALITIES OF METAL PARTS, SPARS, PINS AND BOLTS - ALL BOLTS AND NUTS IN POSITION
Pitot-static lines and wing tip lights electrical cables:	- CONNECTED PROPERLY AND IN POSITION
Instrument panel and instruments:	- VISUAL INSPECTION
ELT / ELT remote switch	- CHECK: ELT switch/remote switch positions according to table page 7-6.
Master switch OFF:	- NO CONTROL LIGHTS AND/OR ELECTRONIC INSTRUMENT ACTIVITY
Master switch:	- ON
Avionics switch > ON:	- EPSI570 IS ENABLED, instruments are ON
EPSI570 display:	- OPERATIVE, CLEAN WITH NO CRACKS.
Make sure you have set all instruments to correct initial setting:	- QNH, COMM FREQUENCY SET
Radio:	- FUNCTION CHECK
Elevator trim:	- VERIFY TRAVEL - SET TO NEUTRAL
Flap handle:	- BUTTON SPRING FIRM - LOCKING MECHANISM WORKING PROPERLY - SMOOTH MOVEMENT ALONG FULL DEFLECTIONS - NO FREE PLAY OR VISIBLE DAMAGE
Parking brake:	- APPLIED
Controls:	- FREE ALL/ANY OBSTRUCTIONS
PWR EN/THR EN switches > ON:	- CHECK - no warnings (EPSI570 display)
Battery %SOC, temperature and status:	- CHECK VALUES / CHECK TEMP - green (EPSI570 display)
Power controller status:	- CHECK / CHECK TEMP - green (EPSI570 display)
Motor status:	- CHECK / CHECK TEMP - green (EPSI570 display)
Battery packs	- CHECK status Active (EPSI570 display)
Doors - Safety belts:	- Closed/secured - fastened
Motor check: cut off - full - cut off	- CHECK - no warnings (EPSI570 display)

Minimum conditions for active motor

WARNING! When the following conditions are fulfilled, the motor is **ACTIVE** and will start running as soon as the power lever is moved forward from the **CUT OFF** (idle) position!

Master switch	ON
PWR EN switch	ON
THR EN switch	ON
PWR CTRL circuit breaker	ENGAGED
HV BAT.1 circuit breaker	ENGAGED
HV BAT.2 circuit breaker	ENGAGED

Normal procedures and recommended speeds

To enter the cabin, first lift the door all the way to the wing's bottom surface. The silver knob will grab and secure the door in position. Sit on the cabin's edge and grab it to support your body. Drag yourself onto the seat, lifting only one leg over the stick for best position. Immediately after positioning yourself in the seat, check that the position of the rudder pedals suits your size and needs.

NOTE Rudder pedal position is also adjustable during flight.

To lower the door DO NOT attempt to grab and pull door's handle, but gently pull the silver knob instead. To secure the door, rotate the handle so that it locks and verify that all three closing points are secured.

Fasten the safety belts according to your size.

Adjust the rudder pedals according to your required legroom. Sit inside the cockpit and release the pressure off the pedals. Pull the black knob in front of the control stick to bring the pedals closer to you. To move the pedals further away, first release the pressure of the pedals, then pull on the knob slightly (this will release the locking mechanism). Now push the pedals forward using your feet, while simultaneously pulling on the black adjustment knob.

WARNING! Tighten both the bottom and shoulder straps of the safety harness so that you're completely secured in your seat. This is especially important when flying in turbulent conditions, as turbulence can cause injury to passengers not wearing their safety harness.

Motor start-up

Before motor start-up

CAUTION! To ensure proper and safe use of the aircraft it is essential to familiarise yourself with the motor's limitations and motor manufacturer's safety warnings. Before motor start-up make sure the area in front of the aircraft is clear. It is recommended to start the motor up with the aircraft's nose pointing into the wind.

Check the state of charge to make sure there is sufficient battery power for the planned duration of flight.

NOTE Tests have shown that the battery system does not overheat or behave adversely when the outside air temperature is between -5 °C and 37 °C.

Make sure the pitot tube is uncovered and rescue parachute safety pin removed.
Apply the wheel brakes. Apply parking brake.

Motor start-up

CAUTION! See Motor Start-Up in section "Cockpit electrical system panel" in Chapter 7: If THR EN switch is not "ON", and power lever is not in "cut off" the motor/propeller will not start running. After moving the power lever to "cut off", apply power and the motor will start running.

Motor warm-up procedure

No warm-up is necessary.

Taxi

Release parking brake if set and release the handbrake. Taxiing technique does not differ from other aircraft equipped with a steerable nose wheel. Prior to taxiing it is essential to check the wheel brakes for proper braking action.

Holding point

Make sure motor temperatures at full power range are within operational limits.
Make sure the safety belts are fastened and doors closed and secured at all three closing points.
For short field operations extend flaps 25°. For all other operations extend them to 15°.
Power cut off.

Before takeoff power check

1. Check **PARKING BRAKE is ENGAGED**
2. **INCREASE POWER LEVER to FULL**
3. Check **POWER INDICATION ≥ 56 kW** (EPSI570 - flight page)
4. **CUT OFF POWER LEVER**
5. Check **BATTERIES IN "ACTIVE" MODE** (EPSI570 - system page)
6. Check **ENGINE and BATTERY TEMPERATURES** (EPSI570 - flight page)
7. Check **NO CAUTIONS or WARNINGS** (EPSI570 - flight page)

CAUTION! At **FULL POWER** the motor RPM should be between 2000 and 2500, while the motor power should be 56 kW or more. If this is not the case, do not proceed with flight and check the system for correct installation.

CAUTION! Max battery temperature before takeoff is 40°C (check section 3 - Limitations). Temperatures higher than 40°C at takeoff may result in high in-flight battery temperatures when OAT is high or high power settings are applied. See also section 6 - Emergency procedures.

Takeoff and initial climb

Before lining-up, verify the following:

Parking brake / brakes : Released

Battery SOC: sufficient (see EPSI570 display - page "flight")

Motor - Power controller - Batteries Temperatures: Check - green (see EPSI570 display - page "flight")

Battery packs: Check "Active" (see EPSI570 display - page "system")

Safety belts: fastened

Cabin doors: closed securely

Trim lever: in neutral position

Flap handle: For short field operations extend flaps 25°. For all other operations extend them to 15°

Runway: clear

Now release brakes, line up and apply full power.

Verify motor PWR at full power not less than 56 kW.

CAUTION! Keep adding power gradually, as sudden bursts of power can cause airframe damage on certain runways due to rocks and debris.

WARNING! If the motor PWR is less than 56 kW with power lever in full position, abort take-off immediately, come to a standstill and verify systems.

Start the takeoff roll pulling the control stick one third backward and lift the nose wheel off the ground as you accelerate. Reaching 40-45 kts (75-80 km/h), gently pull on the stick to get the aircraft airborne.

CAUTION! Takeoff with crosswind (lateral component max 18 kts/34 km/h) should be performed by applying control stick pressure into the wind. Special attention should be paid to maintaining runway heading!

Initial climb

When airborne, apply brakes momentarily to prevent in-flight wheel spinning.

Accelerate at full power and maintain proper climbing speed.

At safe altitude (above 150 ft /50 m), retract the flaps to 15°. Retract the flaps to 0° when reaching 70 kts (130 km/h) at 300 ft (100 m). Reduce power to 40 kW and continue climbing at 76 kts (140 km/h).

Adjust the trim to neutralise stick force if necessary.

CAUTION! Remember to keep the motor/power controller/battery temperatures and RPM within operational limits during climb out.

CAUTION! Reduce power and lower nose (i.e. increase speed) if additional motor cooling is required.

Cruise

When horizontal flight has been established, verify on-board energy quantity again.

Keep the aircraft balanced while maintaining desired flight parameters.

To conserve energy, cruise at 85 kts (157 km/h) or slower.

Cruising in rough conditions

Should you experience turbulence, reduce airspeed below VNO and continue flying with flaps retracted (0°).

CAUTION! In rough air, reduce motor power if necessary to keep airspeed below VNO.

Descent and final approach

Descend at speeds at or below VNO with the flaps retracted (0°)

For approach reduce speed to 70 kts (130 km/h) and extend flaps to 15° only after turning to base leg. Adjust motor power to maintain proper airspeed. Set the trim to neutralise stick force if necessary. During the descent, monitor temperatures and keep them within operational limits.

CAUTION! With power lever set close to cut off, the motor will recuperate energy during the descent and the vertical sink speed will increase, similar to the effects of airbrakes on sailplanes.

On final, reduce speed to 60 kts (111 km/h) and extend flaps to 25°.

Align the aircraft with the runway and reduce power to cut off.

Maintain an airspeed of 56 kts (104 km/h).

Use the power lever to control your descent glide path. Control your attitude and crab if necessary.

CAUTION! Crosswind landings require higher final approach speeds to ensure safe maneuverability. Increase the approach speed by 1 kts for every 1 kts of crosswind component e.g. If there's a crosswind component of 5 kts, increase the approach speed by 5 kts.

Roundout and touchdown

CAUTION! See chapter "Performance" for landing performance.

Roundout and touchdown (flare) occurs at following airspeeds:

Calm air, aircraft at MTOW	40 kts (75 km/h) IAS
Rough air, aircraft at MTOW (incl. strong crosswinds up to 18 kts (34 km/h) of lateral component)	42 kts (78 km/h) IAS

CAUTION! Land the aircraft in such a manner that the two main wheels touch the ground first, allow the nose-wheel touchdown only after speed has been reduced below 25 kts. When lowering the nose wheel to the runway the rudder **MUST NOT** be deflected in any direction (rudder pedals centered).

When on the ground, start the braking action while holding the control stick in full back position. Steer the aircraft using the rudder only. If the runway length is sufficient, come to a complete standstill without engaging the brakes, while holding the control stick slightly backwards as you slow down.

Crosswind approach and roundout

CAUTION! Crosswinds prolong landing runway length due to elevated airspeed

When performing a crosswind landing, the wing-low method should be used. When using the wing-low method it is necessary to gradually increase the deflection of the rudder and aileron to maintain the proper amount of drift correction.

WARNING! If the crab method of drift correction has been used throughout the final approach and roundout, the crab must be recovered before the touchdown. Do this by applying rudder to align the aircraft's longitudinal axis with its direction of movement.

Parking

Come to a complete standstill by using the handbrake lever. Shut down the motor. Insert BPRS handle's safety pin. Apply the parking brake. Disengage PWR CTRL circuit breaker. Open cabin door, unfasten safety belts and exit the cabin. Chock the wheels and cover the pitot tube with its protective sleeve.

5 Performance



Introduction (5-2)

**Energy management and mission
planning (5-2)**

Stall speeds (5-2)

Airspeed calibration (5-3)

Takeoff performance (5-4)

Climb performance (5-6)

Cruise (5-7)

Landing performance (5-8)

Crosswind takeoffs/landings (5-8)

Introduction

This section provides information about the aircraft's airspeed calibration, stall speeds and general performance. All data published was obtained from test flight analysis using average flying skills.

The ALPHA Electro has demonstrated adequate motor cooling performance at ambient temperatures of up to 40 °C (104 °F). This is not to be regarded as a temperature limit, however higher temperatures may have an adverse effect on motor cooling and overall performance.

Energy management and mission planning

When flying the ALPHA Electro, it's important to pay special attention to energy and endurance management. The following is a set of SOC depletion guidelines for the different flight stages:

- 1% of SOC for every 100 ft of climb
- 15% of SOC for flight from take-off to the training area 1500 ft AGL and 10 km away
- 10% of SOC for 5 minutes of manoeuvring in the training area (at 20-25kW)
- 10% of SOC to return from the same training area
- 10% of SOC for 1 circuit pattern at 1000 ft AGL
- 7% of SOC for 1 circuit pattern at 500 ft AGL

Increase all of the above by a further 10% in case of high winds and/or turbulence.

Example:

- 10% of SOC for 1 circuit pattern at 1000 ft AGL – in turbulence this circuit pattern would require 11% of SOC.

The flight should be programmed and combined in a way that ensures the SOC at landing is no less than 30%.


NOTE In order to improve battery life not discharging the batteries below 20% SOC is recommended. Normal SOC at the end of flight should always be about 27-30%.

Stall speeds

Stall speeds at MTOM (1256 lbs / 570 kg) for the ALPHA Electro are as follows (IAS):

Flaps 0° (retracted):	44 KIAS (82 km/h)
Flaps +15° (extended):	41 KIAS (76 km/h)
Flaps +25° (extended):	39 KIAS (72 km/h)

Airspeed calibration



Takeoff performance

All data published in this section was obtained under the following conditions:

- Aircraft at MTOM
- Elevation: sea level
- Wind: calm
- Runway: grass runway
- Data extrapolated for ICAO standard atmosphere

ALPHA Electro	ALPHA Electro
Takeoff ground roll at MTOM	595 ft (181 m)
Takeoff runway length (over 50 ft/15 m obstacle)	930 ft (285 m)

NOTE In order to meet the data for takeoff runway length over 50 ft obstacle maintain V_x (55 kts, 102 km/h) after take off.

The runway length required for takeoff may vary depending on the wind, temperature, elevation and wing & propeller surface condition.

Effect of elevation

The table below provides data about the effect of elevation on takeoff runway length.

Elevation (m)	0	500	1000	1500
Elevation (ft)	0	1640	3280	4921
Atmosph. pressure (inHg)	29.92	28.17	26.52	24.95
Atmosph. pressure (hPa)	1013	954	898	845
Outside temperature (°C)	15,0	11,7	8,5	5,2
Outside temperature (°F)	59	53	47	41
Takeoff ground roll [ft] ([m])				
ALPHA Electro	595 (181)	750 (228)	930 (285)	1165 (355)
Takeoff distance over 50 ft / 15 m obstacle [ft] ([m])				
ALPHA Electro	930 (285)	1100 (338)	1385 (422)	1520 (465)

WARNING! The runway length required for takeoff is affected by several factors like elevation, OAT, runway conditions.

Effect of the wind

Wind (head, cross or tailwind) affects aircraft's ground speed (GS).

Headwind on takeoff or landing causes the takeoff and landing distance length to shorten as the GS is smaller during these two flight stages. The opposite holds true for tailwind on takeoff and landing as tailwind prolongs takeoff and landing distances significantly.

WARNING! Tailwind affects takeoff and landing performance by more than twice as much as headwind does.

The table below provides data about the effect of headwind (+) and tailwind (-) on the runway length required for takeoff and landing (referenced for sea level conditions, airplane at MTOM). Relative effect is maintained at any elevation.

		Windspeed													
kts	(km/h)	-6	(-11.1)	-4	(-7.4)	-2	(-3)	0	(0)	4	(7.4)	8	(14.8)	12	(22.2)
		Takeoff runway length [ft] ([m])													
ALPHA Electro		730 (221)		690 (210)		647 (197)		595 (210)		560 (171)		530 (162)		515 (157)	
		Takeoff distance over 50 ft / 15 m obstacle [ft] ([m])													
ALPHA Electro		1210 (370)		1140 (348)		1035(315)		930 (325)		867 (265)		815 (248)		770 (235)	

Climb performance

ALPHA Electro	ALPHA Electro
Best climb speed (V_y)	70 kts (130 km/h)
Best climb rate at MTOM, sea level	590 fpm (3.0 m/s)

NOTE Climb rate is measured at a max continuous motor power of 40 kW with the flaps retracted (0°) at V_y and MTOM.

CAUTION! Remember to keep the motor/power controller/battery temperatures within operational limits during climb. Avoid unnecessary use of high power settings if not necessary, especially in high outside temperature.

Effect of outside air temperature

For every 5 °C (10 °F) increase in OAT versus the ISA, the climb rate decreases by 60 fpm (0.3 m/s).

Effect of altitude

The table below provides data about the effect of elevation on climb rate at best climb speed V_y at MTOW.

ALPHA Electro	ALPHA Electro
0 m (0 ft)	590 fpm (3.0 m/s)
500 m (1600 ft)	575 fpm (2.9 m/s)
1000 m (3300 ft)	545 fpm (2.7 m/s)
1500 m (5000 ft)	510 fpm (2.6 m/s)

NOTE Climb rate is measured at a max continuous motor power of 40 kW with the flaps retracted (0°) at V_y and MTOM.

Climb performance may vary depending on, temperature, altitude, humidity and wing & propeller surface condition.

Cruise

Aircraft at MTOM, recommended cruise power of 20-30 kW in international standard atmosphere (ISA), sea level altitude, flaps retracted (0°):

ALPHA Electro	ALPHA Electro
Cruise airspeed	85 kts (157 km/h)

Cruise energy calculation

When flying the ALPHA Electro outside the circuit pattern, it is important to estimate when the remaining energy is sufficient for a safe return to home base. The PNR (Point of No Return) in flight is when we have just sufficient %SOC to return to base (and arrive there with 30%). This PNR is calculated for flights from point A to point A (A-A). Most ALPHA Electro flights are A-A.

NO WIND CONDITION - EXAMPLE

When flying in no wind conditions along a straight track, calculating our PNR is not particularly difficult. We have enough %SOC available to take off and fly toward our destination along our track knowing, as long as we do not proceed beyond the halfway point, we should be able to make it back to home airfield safely.

If we start with 100% SOC. We have to be back with 30%. Therefore we have a usable SOC of 70%. Half of this useable SOC is 35%. So, we have to turn back towards the home base - mission accomplished or not - at 65% of SOC. The halfway point is 65% of SOC. This is only true if we start with a full charge.

WINDY CONDITIONS - EXAMPLE

Cruise speed 85 kts IAS, and we have an outbound tailwind of 15 kts (from GPS ground speed reading). The difference between the IAS and TAS at ALPHA Electro altitudes are negligible and we can take the IAS as TAS.

Therefore:

GS outbound: 85 kts + 15 kts (tailwind) = 100 kts

GS inbound: 85 kts - 15 kts (headwind) = 70 kts

The %SOC to PNR is calculated with the PNR equation:

$$\%PNR \text{ SOC} = \text{useable SOC} \times \text{GS homebound} / (\text{GS homebound} + \text{GS outbound}).$$

In our example, this is: $70\% \times 70 \text{ kts} / (100 \text{ kt} + 70 \text{ kts}) = 28\%$, that is the %SOC used to reach PNR.

So our PNR is $100\% - 28\% = 72\%$, where 100% is the initial SOC in this example.

This is very important. If we are flying with a tailwind we have to turn back to the point of origin much sooner.

Landing performance

Final approach speed should be 56 kts (104 km/h) with flaps extended to +25°. The required landing runway length may also vary depending on the elevation, gross weight, touchdown velocity, wind direction and how aggressive the braking action is (i.e. recuperation).

The landing roll measures 440 ft (135 m) in the following conditions: aircraft at MTOM, airport at sea level and wind calm.

Total landing distance over 50 ft/15 m obstacle measures 1615 feet (492 m).

Landing roll increases by 10% for every 2000 ft (610 m) increase in density altitude.
Total landing distance increases by 2% for every 2000 ft (610 m) increase in density altitude.

Energy recuperation decreases required runway length and makes the approach steeper!

Crosswind takeoffs/landings

The maximum allowed crosswind component speed on takeoff and landing is 18 kts (34 km/h).
In these conditions it is recommended not to takeoff with flaps positioned at +25°.

Normal crosswind landings are made with flaps extended to +15°. Avoid prolonged slips. After touchdown, hold a straight course with rudder and brakes as required.

Only in case of high crosswind component it is permitted to land with flaps retracted (0°).

The runway length required increases by 10% for every 5 kts of crosswind component.

6 Weight and balance



Introduction (6-2)

Weighing procedure (6-2)

Equipment list (6-3)

Determination of CG (6-3)

Sample CG calculation (6-4)

Introduction

This section describes the procedure for establishing the basic empty weight and moment of the airplane. Sample calculations are provided for reference. Specific information regarding the weight and arm for this airplane as delivered from the factory can be found in the aircraft documentation folder, look for Weight and Balance Report.

WARNING! It is the responsibility of the pilot to make sure the airplane is loaded properly. Operation outside of the prescribed weight and balance limitations could result in an accident and serious or fatal injury.

Weighing procedure - (see also in WBR document)

Make sure all listed aircraft parts and appliances are installed and in position. Remove all other objects (e.g. tools, rags, tie downs and other items ...). Install batteries. Retract flaps and leave control surfaces centered.

Level the aircraft inside a closed spaced using a digital level. Calibrate it so that it reads 0° when placed on the levelling surface (i.e the surface the aircraft is on). Then use it to make the tail cone's center line parallel to the levelling surface. Do this by placing the level on the upper surface of the tail cone just fore of the vertical stabilizer and measuring the angle. Do the same on the tail cone's lower surface. The aircraft (tailcone centerline) is level once these two readings are the same (or use the tail leveling tool/template).


Once levelled, read the scale readings and subtract eventual tare weight.

Now record all readings and fill out the bottom table.

The datum is the wing's leading edge at the fuselage root. Calculate the lever arm of CG using this formula:

Weighing form (EAW and empty CG determination)

	Scale reading	Tare	Net
Right main wheel (GR)			
Left main wheel (GL)			
$G_1 = GR + GL$			
Nose wheel (G2)			
Total EAW ($GEAW = GR + GL + G_2$)			
Empty CG location (CGmm):			
$CG_{mm} = \frac{b \times G_1 - a \times G_2}{(G_1 + G_2)}$			



Equipment list

The aircraft's empty weight data is unique for each and every ALPHA Electro delivered. The owner is responsible for keeping the equipment list up to date. Fill it out according to actual status.

ALPHA Electro

Serial number:

Registration number:

Equipment installed:

Determination of CG (operative/loaded aircraft)

	Weight (kg)	Weight's lever arm (mm)	Moment (kg x mm)	Remarks
Basic cfg. EAW	*	*		
Instruments (additional)		- 310		minus!!!
Pilots		370		
Total weight and moment				
CG (loaded aircraft) : = Total moment/total weight	=			

* **NOTE** use empty aircraft weight (EAW) and empty aircraft CG(mm) values found in the WBR document for the specific aircraft.

CAUTION! Each newly installed part or appliance must be registered in the upper table. Also, the new total weight and lever arm of CG values must be entered and the position of CG re-determined. Furthermore, the moment must be recalculated. This is rather easy to do. First multiply the new part's weight by it's lever arm measured from the reference point (wing's leading edge). Then sum up all moments and divide the sum by the new total weight.

WARNING! The aircraft's in-flight safe center of gravity position ranges between 8 1/16" (220 mm) and 14" (355 mm) aft of datum and is not critically affected by cockpit crew weight.

WARNING! Storing luggage or any other items in the battery bays is strictly prohibited!

Sample c.g. calculation

GEAW is the total mass of empty aircraft. All calculations can be performed with aircraft empty weight and empty weight center of gravity (CGmm).

Basic CG formulas and calculation

Read thoroughly.

NOTE all the values in the following calculation will be used purely as an example.

1) Weigh the aircraft according to the procedure described in this chapter and write down values of G_1 (sum of scale readings at main wheels) and G_2 (scale reading at tail/front wheel). Then calculate the position of empty c.g. in millimeters (CGmm) from the datum (wing's leading edge at wing root).

Use the following formula:

$$CG_{mm} = \frac{b \times G_1 - a \times G_2}{(G_1 + G_2)} = \frac{505 \times G_1 - 1020 \times G_2}{(G_1 + G_2)} = 275 \text{ mm}$$

where:

a is the measured distance from nose wheel axis to wing's leading edge,

b is the measured distance from main wheel axis to wing's leading edge (average of the two),

2) Determine the weight and CG of the loaded/operative aircraft:

	Weight (kg)	Weight's lever arm (mm)	Moment (kg x mm)	Remarks
Basic cfg. EAW	380	275	104500	
Instruments (additional)	/	- 310	/	minus!!!
Pilots	70+70	370	51800	
Total weight and moment	520		156300	
CG (loaded aircraft) : = Total moment/total weight	= 156300 / 520 = 301 mm			

It is also possible to determine the c.g. position as percentage (%) of Mean Aerodynamic Chord (MAC) with following the formula:

$$CG\%_{MAC} = \frac{CG - R}{MAC} \times 100 = \frac{301 - 40}{900} \times 100 = 29\% \text{ MAC}$$

where:

CG is the position of CG of the loaded aircraft in millimeters (mm),

R is the difference between wing's leading edge and MAC's leading edge (40 mm),

MAC is the Mean Aerodynamic Chord (900 mm).

3) Verify that weight and CG limitations are respected (see section "Limitations").

In this example, the aircraft total weight is 520 kg and is lower than the MTOM.

The in-flight CG location is 301 mm (29% MAC) and is within the prescribed CG range limits.

7 Aircraft & systems



Introduction (7-2)

Cockpit controls (7-3)

Instrument panel (7-3)

Undercarriage, wheel and brake system (7-6)

Seats and safety harnesses (7-6)

Pitot-static system (7-6)

ELT (7-6)

Power plant, propeller and energy storage (7-7)

Energy storage and charging (7-8)

CAN (data) Logger (7-11)

Introduction

The ALPHA Electro is a 34' 5 3/8" (10.5 m) wing-span, two-seat T-tail high-wing motorplane made almost entirely of composite materials.

It has a robust, tricycle undercarriage that incorporates brake-equipped wheels, a U-shaped composite strut and a steerable nose wheel.

The ALPHA Electro features flaperons, meaning that one movable surface on each wing acts both as the flap and the aileron. Flaps offer 3 settings: retracted 0°, +15° and +25°.

Full dual main flight control levers make the ALPHA Electro ideal for initial and advanced flight training. All aileron, elevator and flap controls are connected to the cabin controls using self-fitting push-pull tubes. The rudder is controlled via cables. The elevator trim is electric.

All aircraft are shipped with 4-point safety belts attached to the fuselage at three mounting points. The rudder pedals can be adjusted before and also in-flight to suit your size and needs.

The aircraft is equipped with two battery packs: one is located aft of the cabin bulkhead and the other is aft of the firewall. The battery system is ventilated and thermally protected.

The electric motor is a 60 kW peak power unit capable of energy recuperation during descent.

The windshield, doors and top window are made of 2 mm anti-UV tinted Lexan, which was specially developed not to shatter or split on impact.

The main wheel brakes are hydraulically driven drum type and activated via a cockpit hand-lever. The hydraulic brake fluid used is DOT 4.

Cabin ventilation is achieved through special vents fitted into the doors.

The propeller is a fixed pitch three-blade design.


The resettable electric circuit breakers enable the pilot to test individual circuit items and disconnect the batteries from the circuit if required.

Navigational (NAV) lights, anti collision (AC) lights and a landing (LDG) light are installed.

The firewall is reinforced with heat and noise insulation.


Basic instruments come installed with operational limits pre-designated.

A BPRS is present and located in aft fuselage.



Cockpit controls

The ALPHA Electro cockpit levers are divided into two groups:




Individual control levers: pilot stick and rudder pedals

Dual control levers: power lever, handbrake lever, flap lever, trim lever, door handles and BPRS release handle.

Instrument panel

The instrument panel is equipped with various instruments/gauges that indicate airspeed, altitude, RPM, etc.. It includes: artificial horizon, EPSI570 electric system parameters (monitors RPM, power controller temperature, motor temperature, coolant temperature, state of charge, battery temperature and state of health), radio Garmin GTR200, transponder Garmin GTX335 and the GPS Garmin AERA 660. Instructions on how to use the instruments/gauges (COM, GPS) are found in individual equipment manuals, which are to be considered supplement to this POH. The gauges are round and 80 mm or 57 mm in diameter, while the GPS has a touchscreen. The radio is a modern lightweight unit, features full VOX intercom and dual PTT connections..

NOTE See appendix (section 9) for additional details about the EPSI570



Cockpit electrical system panel (switch panel):

The cockpit electrical system panel incorporates a separate master switch, avionics switch, separate battery enable and power enable switches. There are fuses located in the illuminated rectangular toggle switches, which are wired behind the avionics switch to each of the electrical avionics loads. Label positions may vary.

When using the cockpit electrical system panel, use the following sequence:


MOTOR START-UP		MOTOR SHUT-DOWN	
PWR CTRL BREAKER	ENGAGE	OTHER SWITCHES	OFF
MASTER SWITCH	ON	THROTTLE ENABLE SWITCH	OFF
AVIONICS SWITCH	ON	POWER ENABLE SWITCH	OFF
POWER ENABLE SWITCH	ON	AVIONICS SWITCH	OFF
THROTTLE ENABLE SWITCH	ON	MASTER SWITCH	OFF
OTHER SWITCHES	ON as desired	PWR CTRL BREAKER	DISENGAGE

CAUTION! If THR EN (Throttle Enable) switch is not “ON” and power lever is not in “cut off” the motor/propeller will not start running. After moving the power lever to “cut off”, apply power and the motor will start running.

NOTE disengage all of the circuit breakers if the motor and/or any other equipment on the aircraft remains on after the master switch is turned off. Engage them before commencing with the next motor start-up.

WARNING! Make sure that “PWR CTRL” circuit breaker is always disengaged when the aircraft is parked on the ground.

Switch panel:



Switches and breakers description:

MASTER	Enable system switch
AVIONICS	Enable instruments switch
PWR EN	Power enable switch
THR EN	Throttle enable switch
SOCKET	12 VDC socket switch
LDG LIGHT	Landing light switch
NAV/AC LIGHTS	Navigation/ anti- collision lights switch
COCKPIT LIGHT	Cockpit light switch
COM	Radio circuit breaker
GPS	Navigation system circuit breaker
XPDR	Transponder circuit breaker
INSTR	Other instruments circuit breaker
EIS	EPSI570 Information System circuit breaker
TRIM	Trim actuator circuit breaker
PUMP	Coolant pump circuit breaker
PWR CTRL	Power control circuit breaker
MAIN SYS	Main system circuit breaker
CHGR	Charger circuit breaker
HV BAT.1	Battery 1 circuit breaker
HV BAT.2	Battery 2 circuit breaker

Undercarriage, wheels and brake system

The tricycle undercarriage incorporates brake-equipped wheels, a U-shaped composite strut and a steerable nose wheel. The rudder pedals are used to steer the nose wheel.

Distance between main wheels:	63" (1.6 m)
Distance between main and nose wheel:	60" (1.52 m)
Tire, 6 ply:	4,00" x 6" (main wh.), 4,00" x 4" (nose wheel)
Recommended tire pressure:	2.8 bar/40 psi (main), 1.8 bar/26 psi (nose)
Brakes:	drum type, actuated by cockpit hand lever, parking brake included
Brake fluid:	DOT 4

The parking brake is applied using a lock pin on the handbrake lever. To apply it, pull the handbrake lever firmly and, while holding it back, slide the lock pin downwards into its respective groove. To release it, simply pull back on the handbrake lever, pull the lock pin out of its groove and release handbrake lever.

Seats and safety harnesses

The ALPHA Electro comes equipped with either stiff, leather seats or soft, fabric-covered seats. The former can be easily removed and the later folded forward, making it easy to access the aft fuselage. Seat position is fixed, whereas pedal position is adjustable. Custom made seats are available for ordering. All ALPHA Electro ship with H type safety harness attached to the fuselage at three mounting points.

Pitot-static system

The Pitot-static tube is attached to the bottom side of the starboard wing. The Pitot lines run through the inside of the wing to the fitting placed on the wing/fuselage joint. Then the lines go to the instrument panel.

ELT (Emergency Locator Transmitter)

The ALPHA Electro can be equipped with an Emergency Locator Transmitter (ELT). The device is composed by the ELT transmitter, installed behind the right seat, a remote switch mounted on the instrument panel, connecting wires and antenna. In the event of an aircraft accident, these devices are designed to transmit a distress signal on different frequencies (121.5 and 406 MHz). The ELT is activated either automatically, once a certain force threshold is reached (e.g. in case of incident) or manually, by setting the remote switch, installed on the instrument panel, to ON. Two ELT models can be found on the aircraft: Kannad 406 AF or Artex 345.

For correct operation of the system, following switches position must be ensured:

	Artex 345		Kannad 406 AF	
	ELT (box)	Remote switch	ELT (box)	Remote switch
Flight position (normal):	ARM/OFF	ARM/OFF	ARM	ARMED
Manual activation during emergency landing:	use remote switch	ON	use remote switch	ON
Manual activation (after emergency landing):	ON	ON	ON	ON
End transmission:	ON>ARM/OFF	ON>ARM/OFF	OFF	RESET/TEST

NOTE Please refer to OEM documentation for periodical testing procedure and additional information.

NOTE If the ELT is inadvertently activated in its distress mode, the operator should deactivate it AND contact the nearest COSPAS-SARSAT Mission Control Centre or local RCC as soon as possible to request cancellation of the distress alert (Deactivating the ALT alone does NOT cancel the distress alert that already has been transmitted by the beacon and received by COSPAS-SARSAT).

Powerplant, propeller and energy storage

The ALPHA Electro has a out-runner type electric motor that provides direct-drive to the propeller. The motor is a 3-phase synchronous motor with permanent magnets, which exhibits high torque and above average efficiency ratings. Motor and power controller cooling is provided by a fluid based system and radiator. The power controller is mounted inside the fuselage in an IP54 enclosure. All components are protected against rain.

The system is controlled by a color-display EPSI570 cockpit interface instrument. It indicates the drive mode and important parameters to the pilot. The EPSI570 also communicates with the Battery-Management-System (BMS) and delivers information about the state of charge (SOC) and monitors the charging. All components communicate via the CAN interface with a proprietary communication protocol. The battery state of health (SOH) is displayed in the display incorporated in each battery pack.

Motor:

TEMPERATURE °C	PEM 60MVLC
Maximum takeoff power (1 min)	56 kW
Maximum continuous power	50 kW
Maximum operating temperature	95 °C
Maximum ambient temperature	40 °C
RPM	PEM 60MVLC
Maximum allowable	2500
Takeoff RPM (typical)	2400
Climb RPM (typical)	2250

Power controller:

POWER CONTROLLER	H300A
Nominal power	60 kW
Maximum operating temperature	65 °C
Maximum ambient temperature	40 °C

WARNING! Do not, under any circumstances, attempt to use any other batteries other than Pipistrel factory-supplied batteries. Only use them with the motor and power controller mentioned in this POH.

Propeller type:

FP03-60E	three blade, fixed pitch composite propeller, diameter 64 9/16"(1640 mm)
----------	--

Energy storage & charging

Description:	2 metal battery boxes(packs) which include cells, BMS and communication modules, power and signal connectors
Total battery capacity:	21.0 kWh
Useful battery capacity:	20.0 kWh

CAUTION! In order to maintain battery life, discharging the battery below 20% charge is not recommended. The useful range is considered to be between 20%-100% of system charge.

CAUTION! Once the batteries reach 0% SOC, they will be disconnected from the system. The 12v battery supplying avionics and auxiliary systems will still be available.

The batteries are housed in 2 metal boxes(packs), which contain the battery cells, the BMS and communication modules, as well as the power and signal connectors. One of the packs is positioned fire-wall forward, while the other is aft of the cabin bulkhead. Be sure to always position the pack in the same location, as they're not interchangeable. Make sure that all the connectors (2x power connectors, 2x CAN BUS connector, one of each per pack) are fastened properly before each flight, as indicated in the EPSI570.

NOTE State of health (SOH): SOH is a measure of usable energy in the batteries. It's related to battery age, temperature and how properly the batteries have been used.

NOTE State of charge (SOC): SOC is an indication of the current charge level given the batteries current capability, which depends on SOH

Battery management system (BMS)

Each of the battery packs has an independent BMS, which monitors and balances the system's voltage. All the units communicate with the EPSI570 and log data from each individual battery cell. If an error occurs, EPSI570 will display a message (error code). Contact the manufacturer if this happens. Under normal circumstances the BMS requires no human intervention and is a fully automated system that takes care of itself.

Battery system	PB345V105E-A
Maximum voltage	398 V
Minimum voltage	288 V
Recommended voltage range for storage	355 V - 365 V
Maximum operating temperature	55 °C
Minimum operating temperature	5 °C
Allowable temperature range for storage	10 °C - 40 °C
Minimum charging temperature	0 °C

CAUTION! Temperatures below 10°C will cause a decrease in battery capacity. Plan your flight accordingly.

WARNING! Do not, under any circumstances, attempt to charge the batteries with any third party chargers. Only Pipistrel original equipment must be used.

WARNING! Respect operating and storage temperatures and storage limits at all times. Failure to do so may result in battery damage.

WARNING! If you have purchased another set of batteries, make sure you do not mix the packs between sets. The same group of 2 packs must always be used!

Charging

The charger is a dedicated charger ranging from **3 kW to 20 kW charging power**. Charge time will vary upon battery charge status and electrical power availability from the network. The charger is a world-wide charger and a portable unit which can be connected to any 110V and 240V, 50 Hz or 60 Hz electrical grid or the Solar Trailer.

Charging times

Charger: power setting	~ phases	VAC	Hz	Charging time (approx.)
3 kW	1 ~	85 - 265	45 - 65	8 h
10 kW	1 ~	85 - 265	45 - 65	2 h 30 min
15 kW	1 ~	85 - 265	45 - 65	1 h 45 min
10 kW	3 ~	380	45 - 65	2 h 30 min
20 kW	3 ~	380	45 - 65	1 h 10 min

WARNING! Before connecting the charger, make sure the aircraft electrical system is OFF (Master Switch in OFF position).

FULL CHARGE PROCEDURE (fully charged battery for a flight)

- Plug the charger in.
- Unscrew the **FAST CHARGE PORT** cap.
- Plug the charger into the charging socket located in the nose of the aircraft.
- Power-up the charger using the charger's rocker switch.
- Access the charger's display and it's menu.
- Push the "**FULL CHARGE**" button in the charger display's menu.
- Select the desired charger input current from the left side of the display
- Confirm your selection with the "**CONFIRM**" button.
- The charger will initiate charging.
- The charger's display indicates when charging is completed > press "**CONFIRM**" button.
- To disconnect the charger, turn the rocker switch on the right side of the charger to OFF.
- Remove the charging cable from the **FAST CHARGE PORT**.
- Place the cap back on the aircraft's charging socket.

NOTE After performing a full charge, do not keep the battery charged above 80% STATE OF CHARGE (SOC) for more than 5 days. Either perform a flight or run the motor to discharge the battery to the recommended 50-80% SOC for storage.

NOTE Discharging the battery below 20% SOC can negatively affect battery life and thus is not recommended.

NOTE do not unplug the charger's cable from the fast charge port during the charge procedure


REST CHARGE PROCEDURE (storage charge)

When the aircraft is not in use, **performing a keep-alive (storage) charge once every 90 days is required.**

- Repeat the same procedure as outlined in FULL CHARGE PROCEDURE, but instead of **"FULL CHARGE"** mode select **"REST CHARGE"** mode on the charger display.
- This will charge the battery to an optimum level for aircraft storage.

NOTE After a period of no-flying activity, perform a full charge 24 hour before actual flight.

NOTE After charging has started, the "Rest Charge" and "Full Charge" options disappear.



* THE "ENERGY DELIVERED" VALUE INDICATES HOW MUCH ENERGY HAS BEEN TRANSFERRED SINCE INITIATING THE CHARGING PROCEDURE. IT DOES NOT REPRESENT THE TOTAL AMOUNT OF ENERGY IN THE BATTERIES (FOR THIS VALUE PLEASE REFER TO "STATE OF CHARGE" (SOC)).

CAN (data) Logger

The aircraft is equipped with a CAN logger, which is used for logging CAN (Controller Area Network) bus data and can be assimilated to a flight data recorder. The device consists of Logger (an electronic box) with SD card and attached cable with 15-pin DB-15 Connector which can be connected directly to the main controller through diagnostics port positioned on the right side of the instrument panel.



Data Logger



Instrument panel

Setup procedure

Step	Action
1	Approach the right hand side of the aircraft's control panel and locate the socket marked DIAGNOSTICS.
2	Plug in the 15-pin DB-15 Connector into the DIAGNOSTICS socket.
3	Tighten the screws on the connector with a flat screw driver to the socket.

NOTE: Power supply for the device is provided via the attached cable. Device turns on and Logger starts logging CAN bus data on SD card immediately when aircraft's Master switch is turned to ON position. Device turns off and data logging stops when Master switch is turned to OFF position.

Logging and downloading data, during flight and uploading them to the dedicated on-line Pipistrel electro portal, is highly recommended. Submitting the data to the manufacturer will not only make it easier to provide product support and troubleshooting advice, but also give insight into the aircraft's life history. It also helps the design data owner monitor the fleet and implement design improvements based on performance data analysis.

Login to Pipistrel Electro Portal and follow the instructions to upload the logged data by using the link:

<https://cloud.pipistrel.si/electro>

Contact first **electro.support@pipistrel-aircrafts.com** to receive username and password.

For additional help on setting up Pipistrel's flight logger, please refer to:

<https://cloud.pipistrel.si/electro/help> or contact **electro.support@pipistrel-aircrafts.com**



This page is intentionally left blank.

8 Handling and Servicing



Special inspections (8-2)

Tie down (8-3)

Storage (8-3)

Cleaning (8-3)

**Keeping your aircraft in
perfect shape (8-4)**

Special inspections

After having exceeded VNE or landed in a rough manner:

Check the undercarriage, fuselage & wing surfaces and main spars for abnormalities. It is highly recommended to have the aircraft verified for airworthiness by authorised service personnel.

Battery inspection

Make sure the battery packs are secured and that both cables are properly connected. Check for any signs of wire/cable damage or chafing.

Tie down

Point the aircraft into the wind and retract flaps fully (0°). Chock all three wheels. Put an extra rope around the tail-cone and into the slot between the propeller and the spinner. When using rope of a non-synthetic material, leave sufficient slack to avoid damage to the aircraft. To tie down the tail, tie a rope through the tail skid and secure it to the ground. When finished, cover the pitot tube with a protection cover.

Storage

Ideally, the aircraft should be stored in a hangar. For increased in-hangar maneuverability use of an original Pipistrel push-cart is recommended. Stuff the battery bay cooling inlets with some foam or a rag to prevent the ingress of dirt, dust, small animals, etc..

The BPRS is installed in your aircraft, so make sure the activation handle safety pin is inserted every time you leave the aircraft.

Should the aircraft be stored for a longer period of time (more than 6 months), disconnect the 12V battery in the cockpit to prevent the battery from over-discharging during storage.

CAUTION! Follow the instructions given in the battery/charging section in chapter “Aircraft & systems”.

Cleaning

Use fresh water and a soft piece of cloth to clean the aircraft’s exterior. If you are unable to remove certain spots, consider using mild detergents. Afterwards, rinse the entire surface thoroughly.

The Lexan surfaces are protected by an anti-scratch layer on the outside. To avoid damaging these protective layers and coatings, always use fresh water only to clean the surfaces.

To protect the aircraft’s surface (excluding Lexan surfaces) from the environmental contaminants, use high quality car wax.

The interior is to be cleaned with a vacuum cleaner.

Cover or stuff the battery bay cooling inlets with foam or protective tape to prevent water or cleaning solutions from entering the battery bays.

Keeping your aircraft in perfect shape

In order for the ALPHA Electro to perform the way it should, all of the airframe's surfaces must be cleaned on a regular basis. This is especially true for the wing's leading edges, which can seriously affect performance if left dirty. Cleaning must be carried out carefully, so that the aircraft's composite surfaces don't incur any damage.

Precautions

Rubbing any of the aircraft's surfaces aggressively or polishing any of them is not permitted and, if necessary, can only be carried out by an approved maintenance organization.

Avoid the use of ALL aggressive cleaning solutions and organic solvents whenever possible, including window cleaning spray, benzene, aggressive shampoos etc.

When flying in regions with a lot of bugs in the air the leading edges of the airframe (propeller, wings, tail) need to be protected before flight with antistatic furniture spray cleaner such as Pronto (transparent, manufacturer: Johnson Wax), or something equivalent. When using such spray, do not apply it directly onto the wing but onto a soft cloth instead (old T-shirts are best).

After having finished with flight activity for the day, clean the leading edges of the airframe as soon as possible with a lot of water and a drying towel (chamois, artificial leather skin). This will be very easy to do if the leading edge was sprayed with an antistatic spray cleaner before flight.

Post-flight wash down

Bugs, which represent the most of the dirt to be found on the airframe, are to be removed with clean water and a soft cloth (this can also be done using a drying towel, chamois or artificial leather skin). Begin by soaking all the leading edges of the airframe first. Then wipe the aircraft's entire surface until it is completely dry. Clean the propeller and remove any grease spots separately using a mild car shampoo with a wax.

CAUTION! Do not, under any circumstances attempt to use aggressive cleaning solutions, as you will severely damage the lacquer, which is the only protective layer before the structural laminate.

When using the aircraft in difficult atmospheric conditions (intense sunshine, dusty winds, coastline, acid rains etc.) make sure to clean the outer surface more thoroughly.

CAUTION! Do not, under any circumstances attempt to remove such bug-spots with abrasive sponges and/or rough polishing pastes.

Periodical cleaning of all outer surfaces with car shampoo

It is recommended the aircraft be cleaned from top to bottom using a soft sponge. Be careful not to use a sponge that is contaminated with any fine particles, such as those found in mud and sand, as this could abrade/damage the surface. While cleaning, soak the surface and the sponge many, many times. Use a separate sponge to clean the bottom of the fuselage, as it is usually greasier than the rest of the airframe. When pouring water over the airframe, be careful not to direct it over the charger door, battery inlets, wing-fuselage joining section, BPRS straps and cover, pitot tube, tail static probe and/or motor cowlings.

Always rinse the shampooed surfaces again before they dry, then just wipe the whole aircraft dry using a drying towel, chamois or artificial leather skin. Also, clean the control surface gap seals on the empennage. Lift the seals gently and insert ONE layer of cloth underneath, then move along the whole span of the seal.

Cleaning the transparent Lexan surfaces

All the of the ALPHA Electro's window surfaces are made of Lexan. Cleaning Lexan is not the same as cleaning Plexiglas. It is really important to only use clean water (no cleaning solutions are necessary) when cleaning and a really clean drying towel.

CAUTION! Do not use the towel that was used to dry the airframe's surfaces to dry the window surfaces. Use another unused towel for the window surfaces.

Should the window surfaces be dusty, remove the dust first by pouring water (not spraying!) and gliding your hand over the surface. Glide the drying towel over the surface, squeeze it out and soak it before touching the Lexan again. If there are bugs on the windshield, soak them with plenty of water first, so less wiping is necessary. After drying the window surface, apply some antistatic furniture spray cleaner such as Pronto (transparent, manufacturer: Johnson Wax), or something similar and wipe the surface clean with a separate soft cotton cloth.



This page is intentionally left blank.

9 Appendix



BPRS: use, handling and maintenance (9-2)

EPSI570 System description (9-4)

Charger user action guide (9-10)

Training/familiarisation supplement (9-11)

Conversion table (9-13)

Warranty (9-13)

BPRS: use, handling and maintenance

System description

The BPRS provides you with a chance to rescue yourself from an unexpected situation.

The system is placed inside a durable cylinder mounted on the starboard side of the aft battery bay.

The parachute is inside this cylinder and stored inside a deployment bag with a rocket underneath.

This brand new design deploys a canopy that is not gradually drawn from the container or exposed to distortion by air currents, but it actually opens safely in 0,4 to 0,7 seconds over at 50-60 ft above the aircraft. It incorporates a special deployment bag, which decreases the risk of aircraft debris damaging the canopy.

The BPRS is activated manually, by pulling the activation handle mounted on the top of the cabin bulkhead. After being fired, the main canopy opens and fully inflates in about 3.2 seconds.

WARNING! Activation handle safety pin should be inserted when the aircraft is parked or stored in a hangar to prevent accidental deployment. However, the instant pilot boards the aircraft, the safety pin **MUST** be removed!

Using the BPRS

Typical situations for use of the BPRS are:

- structural failure
- mid-air collision
- loss of aircraft control
- motor failure over hostile terrain
- pilot incapacitation (incl. heart attack, stroke, temp. blindness, disorientation...)

Prior to activating the system (if time permits):

- shut the motor down and set the master switch to OFF
- fasten safety harnesses tightly
- protect your face and body

To deploy the parachute, firmly pull the activation handle out towards the instrument panel until it extends at least 15" (38 cm) out of its housing.

Once you have pulled the handle and the rocket has deployed, it will be about two seconds before you feel the impact produced by two forces. The first force is that of the system stretching. The second force follows after the canopy opens. It will seem as if the aircraft has pulled backwards briefly. The airspeed is reduced instantly and the aircraft begins descending.

As a pilot you should know that the phase following parachute deployment is unpredictable. If in such a situation for the first time, understand that determining where to land and doing so properly is out of your control.

CAUTION! Should you end up in power lines (carrying electrical current), DO NOT under any circumstances touch any metal parts inside or outside the cockpit. This also applies to anyone attempting to help or rescue you. Be aware that anyone touching any part of the aircraft while standing on the ground will probably suffer mayor injury or die of electrocution. Therefore, you are strongly encouraged to confine your movements until qualified rescue personnel arrives at the site to assist you.

After the BPRS has been used or if you suspect any possible damage to the system, do not hesitate and immediately contact the manufacturer!

Handling and maintenance

Prior to every flight all visible parts of the system must be checked for proper condition. Special attention should be paid to corrosion on the activation handle inside the cockpit. Also, the main fastening straps on the outside of the fuselage must be undamaged at all times.

Furthermore, neither system, nor any of its parts should be exposed to moisture, vibration and UV radiation for long periods of time to ensure proper system operation and life.

All major repairs and damage repairs MUST be done by the manufacturer or authorised service personnel.

For detailed information regarding the BPRS please visit: www.gaxysky.cz


EPSI570 System description

EPSI570 is an integrated avionics device which monitors several propulsion system operational parameters on the ALPHA Electro. The display informs the user about system status and shows RPM, power controller temperature, motor temperature, coolant temperature, state of charge (SOC), battery temperature and state of health (SOH).

EPSI570 device is installed on the instrument panel of the aircraft and is located in the center or star-board side depending on the panel configuration. The device is composed of a main display, a selection knob, five buttons (only the first one from the top is functional) and a USB port for software updates.

The device is operative when the AVIONICS switch is engaged. The display is switched off by pressing the first button, which does not deactivate the system, but just turns the screen off.

Rotation of the selection knob allows the user to move from page to page on the display. Warning and caution messages are acknowledged by pressing the selection knob. Next message, if present, will appear.



Display Modes

EPSI570 has three different display modes/pages: Flight mode, System mode and Charge mode. The transition from a mode to another is done by the selection knob rotation. Charge mode page is available during battery charge process.

NOTE values shown in the pictures below are for demonstrative purposes only and do not reflect any specific real operational situation.

FLIGHT mode

FLIGHT mode is the mode used most during flight. It displays the actual operational parameters like RPM and power kW (battery output power). This screen allows the monitoring of component status and temperatures, battery voltage and warning messages as well.

See the picture below for a description of FLIGHT mode page.



1 - RPM actual value, 2 - Battery state of charge (one bar per each battery), 3 - Actual menu page, 4 - Power actual value, 5 - Remaining flight time, 6 - Motor temperature, 7 - Power controller temperature, 8 - Battery temperature, 9 - Battery and aux battery voltage, 10 - System status

SYSTEM mode

SYSTEM mode shows several diagnostic values of the system components. This mode is selected by rotating the knob. Refer to the table below for a short description of the parameters.

FLIGHT		SYSTEM	
BATTERY		DRIVE	
Position:	front rear	NMT state:	1
Mode:	Active Active	Status:	63
SOC/SOH:	88/99 89/100	Temp M/I:	80°/55°
MAX temp:	31° (0) 34° (0)	RPM:	2150/min
MIN U:	4090mV 4100mV		
MAX U:	4100mV 4123mV		
Bus U:	369.0V 373.0V	Coolant:	55°/58°
Batt U:	371.0V 370.0V	Hobbs:	0min
Batt I:	89.0A 75.0A		
PC err:	0 0		
Balancing:	0 0		
Uptime:	5554 6675		
DC/DC		POWER LEVER	
Presence:	yes	Presence:	yes
State:	1	Output:	800
Output U:	1.4V	Scaled:	880
Output I:	2.5A	Final:	870
Input U:	369.0V	Seen zero:	yes
Input I:	0.3A		

BATTERY section	
One column for each battery	
Parameter	Description
Mode:	Battery status (ready = connected ; active = connected and power relays closed ; error)
SOC/SOH:	State Of Charge/ State of Health of the HV batteries
MAX temp:	Shows the max temp inside the battery pack, detected by the temperature sensors integrated. (x) value: number of temperature sensors not working
MIN V: MAX V:	Minimum and Maximum voltage value of the cells in each battery pack.
Bus U:	Voltage on the bus (power lines after the batteries) (0 when batteries are ready but no power transfer)
Batt V: Batt I:	Battery voltage and current. Negative values possible during charging.
PC err:	Pre-Charge error. This value is for servicing purposes.

Parameter	Description
SW / bal:	Software version / balancing (0 = balancing not active ; 1 = active)
Uptime:	Uptime/elapsed lifetime of the battery (minutes)
DC/DC section	
DC/DC converter	
Parameter	Description
Presence:	yes/no: active output to the bus or not
State/SW:	Active output after the converter First number presents State; 0 = not active, 32 = active Second number presents SW, software version
Output V: Output I:	Voltage and current output of the converter
Input V: Input I:	Voltage and current input to the converter
DRIVE section	
Power controller and motor	
Parameter	Description
NMT State: Status:	Status of the power controller
Temp M/I:	Motor and power controller temperatures
RPM:	RPM
Coolant:	Coolant temperature after and before the cooler
Hobbs:	Hobbs meter of the power controller
Isolation:	- Field not used -

POWER LEVER section	
Power lever	
Parameter	Description
Presence:	yes/no: On-line status of the component
Output:	Value (0 to 1000) depending on the linear power position
Scaled:	Value (0 to 1000) - software scaled and adapted output value using a fixed map for the conversion. The relationship between output and scaled values can't be modified by the operator
Final:	Power controller final value (-300 to 1000). It takes the recuperation contribution into account
Seen zero:	yes/no: shows if the power lever has been moved to cut off after battery activation This is a safety feature. The motor can only be started once power lever has been moved to cut off.

Warning and Caution Messages

System or component malfunctions, warnings and errors are shown in the central part of the display when in FLIGHT mode. It is possible to reset the warning and error messages by pressing the knob. The warning and error messages are “descriptive”, and give a basic description of the problem and/or system affected.


NOTE See EPSI570 user action guide in Emergency procedures section of this manual for a complete list of system warnings and cautions that can appear on the EPSI570 during operation.



EPSI570 screen area displaying warning and caution messages

CHARGE mode

CHARGE mode is active during charging process. It displays the actual charging process parameters in the form of a progress bar (100% is charge completed), current, voltage and temperatures of the charger and of the aircraft battery system.



1 - Charge - progress bar %, 2 - Charger - input parameters: AC current (mains), voltage (mains), charger power module temperature, 3 - Aircraft - battery system parameters: DC input current, charging voltage, battery temperature (highest value measured among all temperature sensors).

Charger user action guide

CHARGER	
Error	User action
CONNECTOR UNLOCK FAILURE	<ul style="list-style-type: none"> - Abort charging - Contact technical support at maintainance@pipistrel.si
BALS UNLOCK FAILURE	<p>When this error appears, the cable between the charger and the power source not plugged in properly.</p> <ul style="list-style-type: none"> - Disconnect and re-connect the charging cable
POWER STAGE BOOT FAILURE	<ul style="list-style-type: none"> - Contact technical support at maintainance@pipistrel.si
POWER STAGE INPUT VOLTAGE FAILURE	<ul style="list-style-type: none"> - Abort charging - Contact technical support at maintainance@pipistrel.si
TC NOT PRESENT	<p>This error appears when the TC charging module isn't working.</p> <ul style="list-style-type: none"> - Contact technical support at maintainance@pipistrel.si
RELAY TURN ON FAILURE	<ul style="list-style-type: none"> - Contact technical support at maintainance@pipistrel.si
RELAY TURN OFF FAILURE FAILURE	<ul style="list-style-type: none"> - Contact technical support at maintainance@pipistrel.si
BATTERY VOLTAGE DETECTION FAILURE	<ul style="list-style-type: none"> - Contact technical support at maintainance@pipistrel.si
COMMUNICATION FAILURE	<ul style="list-style-type: none"> - Abort charging - Contact technical support at maintainance@pipistrel.si
EA LOCK FAILURE	<p>When this error appears, the cable between the aircraft and the charger is not plugged in properly.</p> <ul style="list-style-type: none"> - Disconnect and re-connect the charging cable
BATTERY ACTIVATION FAILURE	<ul style="list-style-type: none"> - Abort charging - Contact technical support at maintainance@pipistrel.si
CHARGING RELAY FAILURE	<ul style="list-style-type: none"> - Abort charging - Contact technical support at maintainance@pipistrel.si
UNSUPPORTED BATTERY TYPE	<ul style="list-style-type: none"> - Abort charging - Contact technical support at maintainance@pipistrel.si

Training/Familiarisation supplement

NOTE Pipistrel offers additional computer-based training for anyone interested in becoming more familiar with the ALPHA Electro. Contact Pipistrel to find out more.

This chapter has been written to assist owners/pilots/instructors of ALPHA Electro on their quest to learn how to safely and efficiently fly this aircraft in addition to the information already assembled in the rest of this POH.

Suggested flight training syllabus

This section outlines the suggested flight training syllabus for the familiarisation of pilots with the Pipistrel ALPHA Electro. The training consists of three sorties of around 40 minutes block time each.

After completing the training, each pilot will have acquired knowledge in the following areas:

- General aircraft handling and performance
- Electric propulsion system and its cockpit indication interfaces
- Charging procedure
- In-flight range and endurance management
- Management of emergency situations and emergency procedures

FIRST SORTIE

PRE-FLIGHT

- 1 - Pre-Flight inspection
- 2 - Cockpit systems familiarisation (instruments, avionics, EPSI570)

IN-FLIGHT

- 3 - Takeoff
Flight to a suitable training area 10km away from the base airfield and at least 1500 ft AGL
- 4 - Establish level flight; general flying to establish pitch sights and turns for coordination
- 5 - Cruise flight at normal performance (18-20kW), then at lower airspeed 55-60KIAS (required power increases)
- 6 - Steep turns
- 7 - Stalls: clean and with power cut-off, full power
- 8 - Approach to stall and full power to simulate pitch-up on go-around
- 9 - Back to the airfield to perform traffic patterns with the remaining energy (usually 2-3)

AFTER LANDING

- 10 - Charging procedure
- 11 - Post-flight debriefing
- 12 - Discussion of energy management guidelines (see Energy Management section of this supplement)

SECOND SORTIE

IN-FLIGHT

- 13 - Circuit patterns with standard configuration
- 14 - Short field approach
- 15 - Approach without flaps
- 16 - Engine failure drill on long final
- 17 - Engine failure drill on downwind
- 18 - Go-around before flare height

AFTER LANDING

- 19 - Debrief and discussion on energy management for possible low-state-of-charge go-around

THIRD SORTIE

The third sortie is a flight to a near-by airfield (approximately 25km away) that emphasizes cross-country flying with a limited endurance aircraft. SOC predictions are made along with the calculation of the PNR (Point of No Return).

IN-FLIGHT

- 20 - Cross-country flight to a near-by airfield
- 21 - Approach with go-around
- 22 - Flight back to the base airfield
- 23 - Circuit patterns with remaining energy (usually 2-3)

AFTER LANDING

- 24 - Debrief and discussion on energy management for possible low-state-of-charge go-around

Energy management and mission planning

When flying the ALPHA Electro, it is important to pay special attention to energy and endurance management. Each sortie should be planned carefully and landing should be performed with no less than 30% SOC.

Mission planning and PNR calculation should be part of the training. Information and data for calculation and planning are in Chapter 5 - Performance.

Conversion table

SI	US	US	SI
1 bar	14.5037 psi	1 psi	0.0689 bar
1 mm ²	0.0016 in ²	1 in ²	625 mm ²
1 cm ²	0.1550 in ²	1 in ²	6.4510 cm ²
1 daN	2.2481 lbf	1 lbf	0.4448 daN
1 g	0.0353 oz	1 oz	28.328 g
1 hPa	0.0295 in.Hg	1 in.Hg	33.898 hPa
1 kg	2.2046 lb	1 lb	0.4536 kg/min
1 kg/min	2.2046 lb/min	1 lb.min	0.4536 kg/min
1 l	0.2641 US gal	1 US gal	3.7864 l/min
1 l	1.057 US quart	1 US quart	0.9461 l
1 l/min	0.2641 US gal/min	1 US gal.min	3.7864 l/min
1 daNm	88.4956 lbf.in	1 lbf.in	0.0113 daNm
1 daNm	7.3801 lbf.ft	1 lbf.ft	0.1355 daNm
1 m	3.2809 ft	1 ft	0.3040 m
1 mm	0.0394 in	1 in	25.4 mm
1 cm ³	0.06102 in ³	1 in ³	16.393 cm ³
1 hPa	0.0145 psi	1 psi	68.965 psi

Warranty statement/voids

For applicable warranty terms and conditions please refer to www.pipistrel-aircraft.com.



This page is intentionally left blank.



This page is intentionally left blank.



Pipistrel d.o.o.
SI-5270 Ajdovščina
Slovenija - EU

t +386 (0)5 3663 873
f +386 (0)5 3661 263
info@pipistrel-aircraft.com
www.pipistrel-aircraft.com

Pipistrel Italia
Via Fratelli Rusjan, 26
34070 Savogna d'Isonzo (GO)
Italia - EU

t +39 0481 522000
info.italia@pipistrel-aircraft.com
www.pipistrel-aircraft.com

Pipistrel Vertical Solutions d.o.o.
Vipavska cesta 2
SI-5270 Ajdovščina
Slovenija - EU

t +386 5 366 38 73
f +386 5 366 12 63
info@pipistrel-aircraft.com
www.pipistrel-aircraft.com