PRE TAKE OFF

BREIFING____CONFIRMED
FLAPS___STAGE 1
NAV LIGHTS ___ON
LANDING LIGHT __ON
FLIGHT CONTROLS ___TEST
CABIN ___READY

TAKE OFF/UPWIND

POWER	APPLY 55KW
CHECK SYSTI	EM FOR WARNINGS
CLIMB SPEED	70KIAS
FLAPS	RETRACT
POWER	_REDUCE TO 44KW
LANDING LIG	HTOFF

DOWNWIND

OK
OK
FIXED
CHECKED
OK
80KIAS

APPROACH-FINAL

BREIFING	_CONFIRMED
LANDING LIGHTS	ON
SPEED	<60KIAS
FLAPS	STAGE 2
TRIM	SET
CABIN	READY

MOTOR RESTART IN FLIGHT

POWER LEVERFULL BACK
SWITCHES RIGHT TO LEFT_ OFF
PWR CTRL BREAKERPULL
COUNT TO 3
SWITCHES LEFT TO RIGHT ON
POWER SLOWLY RE-APPLY

RADIO FAILURE IN FLIGHT

RADIO____TURN OFF THEN ON
RADIO____TEST FUNCTION
IF STILL NO FUNCTION
SQUAWK____7600
WHEN IN SIGHT OF ATC TOWER
ROCK AIRCRAFT WINGS
FLY OVERHEAD THE FIELD AND
FOLLOW NORMAL TRAFFIC
PATTERN PROCEDURES

EPSI FAILURE IN FLIGHT

WITH POWER TO MOTOR
DO NOT SWITCH THE MOTOR
OFF, FLY TO THE CLOSEST
AIRFIELD AND LAND
WITHOUT POWER TO MOTOR
ATTEMPT RESTART AND IF

NESCESSARY, COMPLETE EMERGENCY LANDING

POWERTAIN FIRE IN FLIGHT

POWER LEVER_____FULL BACK
MASTER SWITCH_____OFF
PWR CTRL BREAKER _____PULL
PERFORM EMERG. LANDING

EMERGENCY LANDING

SET BEST 6	LIDE SPI	EED_66KAIS
FIELD SELE	ECTION	_DETERMINE
WIND DIRE	CTION	_DETERMINE
HIGH KEY_		2500FT
SURROUNI	DINGS	CHECK
SIZES	SURFACE	SLOPE
MAYDAY	MAYDA	Y MAYDAY
SQUAWK_		7700
STATUS_A	NNOUNC	E ON RADIO
LOW KEY_		1500FT
		_FULL BACK
MASTER S	WITCH	OFF
HARNESSE	:S	SECURE
	LAND OL	JT

PI-AE

Pipistrel Alpha Electro Standard procedures

		BATTER	Y SOC EST	SATTERY SOC ESTIMATION BY VOLTAGE	Y VOLTAGE			
MIN CELL V	4.2V	4.0V 3.90V 3.85V	3.90V	3.85V	3.75V	3.75V 3.64V 3.54V 3.40V	3.54V	3.40V
APPROX. SOC%	100% 90%	%06	%08	%89	54%	42%	30%	20%

DAILY/PRI	FLIGHT INSPECTION
CIRCUIT BREAKERS	CLOSE ALL OPEN BREAKERS
BATTERY RESET	RESET BATTERIES (FIRST FLIGHT OF THE DAY ONLY)
MOTOR/MOTOR COVER	CHECK FOR COOLANT LEAKAGE, FASTENERS AND SCREWS TIGHTENED, MOTOR COVER UNDAMAGED
BATTERIES	CHECK FASTENERS, CONNECTORS AND COOLING INLET/OUTLET CLEAR OF OBSTRUCTIONS
SPINNER/PROPELLER	CHECK UNDAMAGED AND FASTENED
CONTROL SURFACES	INSPECT ALL EDGES, WING TIPS, FLAPERONS, ELEVATOR, RUDDER FOR AIRWORTHINESS
UNDERCARRIAGE	CHECK TYRE PRESSURES, TYRES, BRAKES AND UNDERCARRIAGE FOR DAMAGE/WEAR
PITOT STATIC TUBE	REMOVE COVER, CHECK FOR INSECT INGRESS AND GENERAL AIRWORTHINESS
MAIN WING SPARS AND CONNECTORS	- VISUAL INSPECTION, BOLTS TIGHT + IN POSITION
PITOT STATIC LINES/ NAV LIGHT CABLES	- CONNECTED PROPERLY AND IN POSITION
MASTER, AVIONICS SWITCH	ON: - EPSI570 IS ENABLED, INSTRUMENTS ON, ALL INSTRUMENTS CLEAR OF OBSTRUCTION/DAMAGE
FLIGHT LOG	ACKNOWLEDGE MAINTENANCE RELEASE AND START FLIGHT IN BREEZYLOG
SET ALL INSTRUMENTS TO INITIAL SETTING	QNH, TRANSPONDER, COMM FREQUENCY, AH CALIBRATION
RADIO	CHECK, (REQUEST START/TAXI CLEARANCE)
ELEVATOR TRIM	- VERIFY TRAVEL, SET TO NUETRAL
FLAP HANDLE	LOCKING MECH FIRM, SMOOTH MOVEMENT
PARKING BRAKE	APPLIED
CONTROLS	FREE OF ALL/ANY OBSTRUCTIONS
DOORS SAFETY BELTS	CLOSED, SECURED/FASTENED
BPRS SAFETY PIN	REMOVE AND STOW
BATT EN, PWR EN SWITCH	ON - CHECK BATTERY %SOC, CHECK VALUES/ CHECK TEMP, NO WARNINGS
POWER AND BRAKES	CELAR PROP, APPLY POWER, TEST BRAKES
COOLANT TEMP M/I	CHECK DURING TAXI FOR PROGRESSIVE CHANGE
TURN OVER FOR AIR SIDE PROCEDURES	TURN OVER FOR AIR SIDE PROCEDURES
SHUT DOWN PROCEDURE	
BATT EN, PWR EN SWITCH	OFF
FLIGHT LOG	CLOSE FLIGHT IN BREEZYLOG, NOTE BATTERY SOC% IN THE LOG ENTRY
MASTER, AVIONICS SWITCH	OFF
BPRS SAFETY PIN	RETURN TO SAFE (LOCKED) POSITION ON BPRS LEVER
PITOT STATIC TUBE	REFIT COVER
CIRCUIT BREAKERS	IF CHARGING, ISOLOATE PWR CTRL BREAKER, IF NOT CHARGING, ISOLATE BOTH PWR CTRL AND MAIN SYS